

OPERATION, SERVICE & PARTS MANUAL

WIRE ROPE HOISTS



GLOBAL KING™

ELECTRIC WIRE ROPE HOISTS

Before installing hoist, fill in the information below.
Refer to the Hoist and Motor data plates.


Model No. _____
Serial No. _____
Purchase Date _____
Voltage _____
Rated Load _____

RATED LOADS THRU 3.2 METRIC TONNE

Follow all **instructions** and **warnings** for inspecting, maintaining and operating this hoist.

The use of any hoist presents some risk of personal injury or property damage. That risk is greatly increased if proper instructions and warnings are not followed. Before using this hoist, each operator should become thoroughly familiar with all warnings, **instructions and recommendations in this manual. Retain this manual for future reference and use.**

Forward this manual to operator. Failure to operate equipment as directed in manual may cause injury.



A-FRAME MODEL

P/N: 11817505 REV. AD October 2018

**YALE HOIST PARTS AND SERVICES ARE AVAILABLE IN THE
UNITED STATES AND IN CANADA**


As a YALE Hoist and Trolley user you are assured of reliable repair and parts services through a network of Master Parts Depots and Service Centers that are strategically located in the United States and Canada. These facilities have been selected on the basis of their demonstrated ability to handle all parts and repair requirements promptly and efficiently. To quickly obtain the name of the Master Parts Depot or Service Center located nearest you, call (800) 888-0985, Fax: (716) 689-5644, visit www.cmworks.com.

**LAS PIEZAS Y REPARACIONES DE LOS POLIPASTOS DE YALE ESTÁN ASEGURADAS
EN ESTADOS UNIDOS Y CANADÁ**

Como usuario de un polipasto y carro de YALE le aseguramos cualquier reparación o la disponibilidad de cualquier pieza de repuesto a través de una red de almacenes de piezas de repuesto y centros de servicio situados estratégicamente en Estados Unidos y Canadá. Estas instalaciones se han seleccionado en base a su capacidad demostrada en la reparación de equipos y suministro de piezas de repuesto de forma rápida y eficaz. Para obtener la dirección del almacén de piezas de repuesto o del centro de servicio más cercano, llame al teléfono (800) 888-0985. Fax: (716) 689-5644, visita www.cmworks.com. (sólo en Estados Unidos y Canadá).

**LE SERVICE DE RÉPARATION ET DE PIÈCES POUR PALANS YALE EST DISPONIBLE
AUX ÉTATS-UNIS ET AU CANADA**

Soyez assurés qu'en temps d'utilisateur de palan et treuil YALE, d'un service de réparation et de pièces fiable par l'entremise d'un réseau de Centres de service et de Dépôts de pièces maîtresses qui sont stratégiquement situés aux États-Unis et au Canada. Ces établissements ont été sélectionnés sur une base de leur habileté démontrée à s'occuper promptement et efficacement des besoins de réparation de pièces. Appelez le (800) 888-0985, Fax: (716) 689-5644, visitez www.cmworks.com. pour obtenir rapidement le nom du dépôt de pièces maîtresses ou du centre de service situé le plus près.



FOREWORD

This manual contains important information to help you install, operate, maintain and service your new YALE electric hoist. We recommend that you study its contents thoroughly before putting the hoist into use. We also recommend that you read Section IX - Series Lifting Equipment of the European Federation of Materials Handling and Storage Equipment (FEM) and the applicable performance and safety standards referenced therein. Then, through proper installation, application of correct operating procedures, and by practicing the recommended maintenance procedures, you can expect maximum lifting service from the hoist.

It will likely be a long time before parts information found in the Parts List is needed. Therefore, after the hoist is installed and you have completely familiarized yourself with operation and preventative maintenance procedures, we suggest that this book be carefully filed for future reference.

When ordering replacement parts from this book, it will be necessary that you include with your order: the Hoist Serial Number and Model Number that are found on the nameplate attached to

the hoist as shown in Figure 4-1. For your convenience, a space has been provided on the front cover of this Manual for entering this information. We recommend that you fill it out immediately so it is readily at hand when needed.

The contents of this manual are of necessity, general in nature and may cover features not incorporated on your hoist; or, you may have ordered features not covered by this manual. Therefore, the user must exercise care in applying instructions given in this manual. If specific information not in this manual is required, contact the factory.

THE INFORMATION CONTAINED IN THIS MANUAL IS FOR INFORMATIONAL PURPOSES ONLY AND YALE DOES NOT WARRANT OR OTHERWISE GUARANTEE (IMPLIEDLY OR EXPRESSLY) ANYTHING OTHER THAN THE COMPONENTS THAT YALE MANUFACTURES AND ASSUMES NO LEGAL RESPONSIBILITY (INCLUDING, BUT NOT LIMITED TO CONSEQUENTIAL DAMAGES) FOR INFORMATION CONTAINED IN THIS MANUAL.

NOTICE: Information contained in this book is subject to change without notice.

INDEX

	Page
SECTION I GENERAL DESCRIPTION	
Paragraph 1-1 General.....	3
Paragraph 1-2 Basic Construction.....	3
Paragraph 1-3 Selection & Application Guide	3
SECTION II INSTALLATION	
Paragraph 2-1 General.....	4
Paragraph 2-2 Installing Hoist.....	4
Paragraph 2-3 Connecting Hoist to Electrical Service.....	5
Paragraph 2-4 Pre-Operational Checks.....	5
SECTION III OPERATION	
Paragraph 3-1 General.....	6
Paragraph 3-2 Push Button Operation	6
Paragraph 3-3 Operating Precautions	6
SECTION IV LUBRICATION	
Paragraph 4-1 General.....	7
Paragraph 4-2 Changing Gear Case Oil	7
Paragraph 4-3 Lubrication of Hoist Cable	8
Paragraph 4-4 Lubrication of Limit Switch	8
Paragraph 4-5 Lubrication of Geared Trolley Wheels and Pinions	8
Paragraph 4-6 Lubrication of Rope Guide.....	8
Paragraph 4-7 Lubricant Specifications.....	9
SECTION V INSPECTION AND PREVENTIVE MAINTENANCE	
Paragraph 5-1 General.....	10
Paragraph 5-2 Inspection Lower Block.....	13
Paragraph 5-3 Inspection Upper Block	13
Paragraph 5-4 Inspection Electrical Controls	13
Paragraph 5-5 Inspection of Rope Guide	13
Paragraph 5-6 Rope Inspection, Maintenance & Replacement.....	14
Paragraph 5-7 Rope Reeving.....	15
Paragraph 5-8 Inspection of Rope Drum & Shaft	16
Paragraph 5-9 Inspection of Hoist Gearing	17
Paragraph 5-10 Inspection of Motor Brake & Actuating Mechanism	18-20
Paragraph 5-11 Inspection of Traverse Drive.....	21
Paragraph 5-12 Testing Block Operated Limit Switch	21
Paragraph 5-13 Testing Over-Capacity Limit Switch	21
Paragraph 5-14 Testing Hoist	21
SECTION VI TROUBLESHOOTING CHART.....	23-24
SECTION VII ADJUSTMENTS	
Paragraph 7-1 Motor Brake Adjustment.....	25
Paragraph 7-2 Block Operated Limit Switch Adjustment	25
Paragraph 7-3 Geared Rotary Limit Switch Adjustment	25
Paragraph 7-4 Over-Capacity Limit Switch Adjustment	25
Paragraph 7-5 Shortening of Push Button Station	26
SECTION VIII WIRING DIAGRAMS	26-28
SECTION IX PARTS LIST	
Paragraph 9-1 General.....	29-34
Paragraph 9-2 List of Parts Illustrations.....	35-49

No part of this document may be reproduced in any form, in an electronic retrieval system or otherwise, without prior written permission of the publisher.

SECTION I - GENERAL DESCRIPTION

1-1. GENERAL

Yale "Global King" electric hoists are wire rope and drum type hoists that are manufactured with an integral trolley. These hoists are all low headroom models with the rope drum and upper block supported on opposite sides of the beam, by the trolley frame. There is one basic frame configuration for both the two and four part single reeved hoists. Both reeving configurations are referred to as "A" Frame hoists with the distinction made between reeving styles. The S4 designation refers to the 3.2 tonne (3200 kg) capacity with a four parts of rope single reeving configuration. The S2 designation refers to the 1.6 tonne (1600 kg) capacity with a two part of rope single reeving configuration. Both hoists feature an integral trolley that are offered with three different flange width ranges; 4-5/8" through 6", 6-1/8" through 10" and 10-1/8" through 14" on a maximum flange thickness of 1-5/8"

Trolley is also available for operation on patented track beams using an optional wheel arrangement and special alignment bars.

The hoist motor is 2-speed with a 4:1 ratio between high and low speeds, as standard. The motor driven trolley has two available speeds with 1, 2 speed, or variable frequency control.

Throughout this manual, you will see references to the "S2" and "S4" Frame hoists. If you are unsure about which frame you have, count the number of rope falls that are supporting the lower block and/or see Section IV, Paragraph 4-2 for a simple gearcase measurement to determine the configuration of your hoist.

1-2. BASIC CONSTRUCTION.

Yale "Global King" hoists consist of a rugged steel frame which houses a lifting drum and serves as the suspension for carrying the entire hoist load. An aluminum gearcase, attached to one end of the drum frame, houses a triple-reduction, helical gear train. Applying power to the gearcase is a 2-speed, AC hoisting motor with a 4:1 speed ratio coupled with a 200% torque DC brake. High strength wire rope and a covered lower sheave block act as the load carrying means. Standard equipment includes a rope guide, a rotary-gear limit switch to limit hook travel in both up and down directions and an overload capacity limit switch. A block operated limit switch can be used to limit the upward travel of the lower block. An integral trolley, consisting of a 2-speed AC motor and a sealed worm reducer, applies torque to the trolley wheels through a cross shaft and pinion arrangement, which provides traverse motion to the hoist. A single NEMA 4/12 control enclosure houses both the hoist and trolley electrical system controls. A push button control station (purchased separately) for operating the hoist is suspended on a wire strain cable attached to the hoist.

1-3. SELECTION & APPLICATION GUIDE.

Hoist Duty Classification

Your YALE "Global King" hoist was designed to meet a specific duty classification as described by the FEM "Rules for the Design of Serial Lifting Equipment". The methodology used to determine the duty class requirements of your specific application is shown below.

YALE "Global King" hoists are defined as "mechanisms" by the FEM and are classified as such by the following factors: **Class of Operating Time** and **Load Spectrum**. Your application must be definable by these two factors in order to determine duty classification.

Class of Operating Time

Class of Operating Time indicates the average period per day during which the mechanism is in operation, which is anytime the equipment is in motion. The Class of Operating Time is determined by calculation of the average daily operating time (average daily use):


Where:

t = Average Daily Operating Time (hr/day)
H = Average Hoist Height (ft)
N = Number of Cycles Per Hour (cycles/hr)
T = Daily Working Time (hr/day)
V = Hoisting Speed (ft/min)

$$t = \frac{2 \times H \times N \times T}{V \times 60}$$

Load Spectrum

Load Spectrum indicates the extent to which the mechanism is subjected to maximum stresses (full capacity lifts) or whether it is subject to smaller loads only. Use the charts below to estimate your load spectrum. For an exact means of calculating your load



spectrum, refer to FEM 9.511 "Classification of Mechanisms".

Once the average daily operating time, "t", is calculated for a specific application, the Class of Operating Time can be identified. Using the Class of Operating Time along with the Load Spectrum, one can determine the duty classification requirement of the application. Defining the proposed equipment usage in this manner is critical to selecting the correct hoist for the application.

Classification of Mechanisms

Load Spectrum	Class of Operating Time				
	T2	T3	T4	T5	T6
	Average Daily Operating Time (hr/day)				
	1/4 - 1/2	1/2 - 1	1 - 2	2 - 4	4 - 8
L1	1Dm	1Cm	1Bm	1Am	2m
L2	1Cm	1Bm	1Am	2m	3m
L3	1Bm	1Am	2m	3m	4m
L4	1Am	2m	3m	4m	5m

Example:

An application requires that a hoist be used to repeatedly lift and move small to medium size loads, but occasionally will be required to lift heavy loads equal to 3.2 metric tonne. This hoist will be operated daily for a single 8-hour shift and will be required to perform 15 lifting cycles per hour. The average height, which the load is lifted, is 18 ft. at a desired speed of 20ft/min.

The average daily operating time can be calculated from the above information:

$$t = \frac{2 \times 18 \times 15 \times 8}{20 \times 60} = 3.6 \text{ hr/day}$$

The description of the example application implies that the load spectrum is likely an L1 or L2. Choosing an L2 load spectrum factor and using the calculated average daily operating time, one can determine from the "Classification of Mechanisms" table above, the duty classification for this application is 2m for a 3.2 metric ton rated hoist.

For a more thorough explanation of the determination of mechanism classification, refer to FEM 9.511 "Classification of Mechanisms".

Your YALE "Global King" hoist was designed to meet the duty classifications as described above. The standard 3.2 tonne and 1.6 tonne capacity models are rated at 2m duty classification. A 3m duty classification is available at a derated capacity.

SECTION II - INSTALLATION

2-1. GENERAL

Yale "Global King" electric hoists are lubricated and tested before being shipped from the factory. To place a hoist in service, install onto beam by adjusting appropriately for the flange width, connect to electrical service and perform pre-operation tests and checks.

WARNING

Only qualified personnel with proper supervision shall install the hoist on the monorail and perform the final pre-operation inspection.

WARNING

Working in or near exposed energized electrical equipment presents the danger of electric shock.

TO AVOID INJURY:

DISCONNECT POWER AND IMPLEMENT LOCKOUT/TAGOUT PROCEDURE BEFORE REMOVING COVER OR SERVICING THIS EQUIPMENT.

2-2. Installing Hoist




Figure 2-1. Trolley Wheel Spacing

OPEN-END BEAM:

If the trolley can be installed directly from the end of the supporting beam, adjust the spacing between the trolley wheel flanges to be 3/16"-1/4" greater than the exact width of the beam flange (See Figure 2-1). Before adjusting the width of the trolley frame, make sure to loosen the pinion set screws on the keyed cross shaft nearest the traverse drive reducer. Do not lose the keys for the pinion during adjustment. Also, the electrical conduit/cable must not be constrained when attempting to adjust the trolley sides, in or out. The trolley width is adjusted by loosening the jam nuts on the traverse drive side of the threaded rods at each end of the hoist. If necessary, lubricate the frame alignment bars with penetrating oil before attempting to adjust trolley width. The trolley side may then be pushed or driven into position by turning the adjusting nuts on the threaded rods. Adjust nuts on each side of the hoist simultaneously, to avoid binding. After adjusting the trolley to the proper width, tighten all adjusting nuts and setscrews, and re-secure the electrical conduit/cable. Verify that the geared wheels mesh properly with the traverse drive pinions. Using proper equipment, carefully lift the hoist and install on the end of the beam. Lubricate the wheel gear and all pinions (WG, Section IV, Paragraph 4-5).

When hoists are adjusted or repaired in the field, all set screws must return to the original settings from the manufacturer. This is done by following the below instructions:

- 1) Apply Loctite 242 to the threads and install the setscrews back into the proper location
- 2) Tighten setscrews for the traverse pinion gear down onto the key and shaft to 70 in-lbs before beginning the use of the hoist

CLOSE-END BEAM:

NOTICE

Loosen all electrical cable or conduit attached to the frame and alignment bars before adjusting trolley width. Ensure that the electrical cable is not stretched, pinched, twisted or otherwise damaged when adjusting trolley width.

For trolleys which are to be mounted along the span of a beam not having open ends, the trolley must be adjusted in the same manner as described above to a width that allows clearance between the axle ends and the beam flange. Using proper lifting equipment, the trolley and hoist must then be lifted to the beam where it is to be installed. Once in position, adjust the spacing between the trolley wheel flanges to be 3/16"-1/4" greater than the exact width of the beam flange (See Figure 2-1). After tightening all adjusting bolts, set screws, and all electrical conduit/cable clamps, carefully set the trolley on the beam. Lubricate the wheel gear and all pinions (WG, Section IV, Paragraph 4-5).

2-3. CONNECTING HOIST TO ELECTRICAL SERVICE

Electrical service to the hoist may be power cable or a guarded system having sliding shoe or wheel type collectors.

Follow ANSI/NFPA 70, state, and local electrical codes including the grounding provisions thereof when providing electrical service to the hoist.

Make electrical connections using the appropriate wiring diagrams furnished with the hoist. Only qualified journeyman electricians shall make any electrical connections, including connections to collectors or power cord.

WARNING

Be certain that electrical power supply is OFF and locked in the open position before attempting any electrical connections to the hoist. This equipment must be effectively grounded according to the National Electric Code ANSI/NFPA 70, or other applicable codes.

CAUTION

Power supply to hoist and trolley must be the same voltage, frequency, and phase that are specified on the hoist and trolley nameplate.

2-4. PRE-OPERATIONAL CHECKS

- a) Check Oil Level. (Figure 2-1) The gearcase has been filled with oil to the proper level. However, this should be rechecked before operating the hoist.

Check oil level by removing the oil level plug indicated in Figure 2-1. When properly filled, oil should be level with the bottom of the tapped hole. Fill to this level with oil as specified in Paragraph 4-2.e.
- b) Check all connections for tightness of bolts, inclusion of lock washers or other type fasteners to ensure correct components have been used. This check must be made for all connections: mechanical, structural and electrical, including both field and factory-made connections.
- c) Check to ensure that all shipping supports, tie-downs, brackets or other items used only for shipping or storage purposes are removed from the equipment.
- d) Check Push Button Operation and Phasing. To properly check the phase of the hoist, follow these steps:
 - (1) With "POWER OFF", operate all the push buttons and determine that they do not bind or stick in any position.
 - (2) Connect hoist to power source.

WARNING

If any push button binds or sticks in any position - DO NOT TURN POWER ON - determine the cause and correct the malfunction before operating.

- (3) Operate "UP" button briefly to determine direction of hook travel.
- (4) If hook raises when "UP" button is depressed, phasing is correct.
- (5) If hook lowers when "UP" button is depressed, hoist is "Reverse Phased." TURN AND LOCK POWER OFF and check the pushbutton wiring. If the pushbutton was wired properly, correct the problem by interchanging any two leads at power source connection. Do not change internal wiring of hoist.

WARNING

On three phase hoists, it is possible to have "Reverse Phasing" causing the block to lower when the "UP" button is depressed. When this condition exists, the automatic limit switch is inoperative and hoist operation will be dangerous.

- e) Check Lower Block and Hoisting Cable. Depress "DN" push button and run lower block to its lowest position. No less than two wraps shall remain on the drum with the loaded hook in its lowest position. Also check to see that the lower block and rope do not twist excessively. If it does twist to the extent that two ropes rub against each other, disengage the swaged rope end from the frame anchor and twist the rope four or five turns in a direction opposite to that which the block turns. Reconnect rope to the frame anchor, holding firmly to eliminate rope twisting back to its original position. Operate hoist up and down a few times. If lower block still rotates excessively, repeat process until twisting is corrected.
- f) Lubricate Hoisting Cable. For longer cable life, it is recommended that the cable be lubricated at time of installation by applying a heavy coating of lubricant CL (Para. 4-7) as outlined in SECTION IV, Paragraph 4-3.
- g) Check Limit Switch Operation.
 - (1) A geared rotary type upper and lower limit switch is provided as standard equipment on YALE "Global King" hoists. This switch is adjustable and although preset by the factory, it should be adjusted at time of installation to the desired high and low limits of lower block travel. Refer to SECTION VII, Paragraph 7-3.
 - (2) A block operated upper limit switch is furnished on YALE "Global King" hoists. This limit stop is factory set to stop the lower block at the safest high position, guarding against over travel and possible damage to hoist. Minimal adjustments can be made. When equipped with this option, the hoist should be tested by jogging the lower block against the limit switch actuator arm to assure the switch is functioning properly. When the lower block lifts the actuator, the hoist will automatically stop. If the lower block coasts through the limit switch when lifting, a reversing switch will automatically close and reverse direction of motion to lowering.
- h) An overcapacity limit switch is provided as standard equipment on YALE "Global King" hoists. This switch is adjustable and although preset by the factory, it should be adjusted at the time of installation to the desired setting. Refer to SECTION VII, Paragraph 7-4.
- i) When first using the hoist and trolley, operate with lighter loads through full travel before applying maximum load.

WARNING

Damage to the hoist, a dropped load, and injury may result if limit switches fail due to improper use.

TO AVOID INJURY:

UNDER NORMAL OPERATING CONDITIONS, STOP HOIST TRAVEL BEFORE ENGAGING LIMIT SWITCHES. LIMIT SWITCHES ARE SAFETY DEVICES AND SHOULD NOT BE USED AS NORMAL OPERATING CONTROL.

WARNING

Some hoists may be shipped with the electrical controls loose (disconnected) and will not have the upper and lower limit switches connected. DO NOT OPERATE HOIST UNTIL LIMIT SWITCHES ARE PROPERLY CONNECTED AND ADJUSTED. Failure to do so may allow hoist to be operated beyond proper travel limits, which can cause load to drop, resulting in damage to equipment or injury.

SECTION III - OPERATION

3-1. GENERAL

Operation of YALE "Global King" hoists is controlled by a convenient pendant push button station. With it, the hoist can be controlled to give fast lifting and lowering; or controlled to lift or lower the load in small increments, providing accurate positioning capability. The push button station has a built-in interlock to prevent depressing opposing buttons simultaneously.

When first using the hoist, break in by operating under lighter loads to full travel before applying maximum load.

3-2. PUSH BUTTON OPERATION

a.) For the hoist motion depress push button marked "UP" to raise load.

b.) For the hoist motion depress push button marked "DN" to lower load.

c.) For the trolley traverse motion:

With two speed control depress buttons marked "<<", ">>" or "N", "S" to activate the trolley traverse motion

With one speed control depress buttons marked "<", ">" or "N", "S" to activate the trolley traverse motion.

d.) On two-speed hoist or trolley motions, partial depression of a button operates hoist or trolley at slow speed; depressing button completely operates hoist or trolley at full speed.

NOTICE

Excessive "jogging" will cause premature burning of contact tips, motor overheating and premature brake wear.

3-3. OPERATING PRECAUTIONS

Safe operation of an overhead hoist is the operator's responsibility. Listed below are some basic rules that can make an operator aware of dangerous practices to avoid and precautions to take for his own safety and the safety of others. Observance of these rules, in addition to frequent examinations and periodic inspection of the equipment, may prevent injury to personnel and damage to equipment.

WARNING

Equipment covered herein is not designed or suitable as a power source for lifting or lowering persons.

- a) **DO** read applicable sections of FEM Section IX, Series Lifting Equipment and the Operation, Service and Parts Manual.
- b) **DO** be familiar with hoist operating controls, procedures, and warnings.
- c) **DO** make sure hook travel is in the same direction as shown on the controls. If opposite direction occurs, see Pre-Operation Checks, Section II, Paragraph 2-4.b.
- d) **DO** make sure hoist limit switches function properly.
- e) **DO** maintain firm footing when operating hoist.
- f) **DO** make sure that the load slings or other approved attachments are properly sized and seated in the hook saddle.
- g) **DO** make sure that the hook latch is closed and not supporting the load.
- h) **DO** make sure that load is free to move and will clear all obstructions.
- i) **DO** take up slack carefully, check load balance, lift a few inches and check load's holding action before continuing.
- j) **DO** avoid swinging of load or load hook.
- k) **DO** make sure that all persons stay clear of the suspended load.
- l) **DO** warn personnel of an approaching load.
- m) **DO** protect wire rope from weld splatter or other damaging contaminants.
- n) **DO** promptly report any malfunction, unusual performance, or damage of the hoist.
- o) **DO** inspect hoist regularly, replace damaged or worn parts, and keep appropriate records of maintenance.
- p) **DO** use the hoist manufacturer's recommended parts when repairing a hoist.
- q) **DO** use hook latches.
- r) **DO** apply lubricant to the wire rope as recommended.
- s) **DO NOT** lift more than rated load.
- t) **DO NOT** use the hoist load-limiting device to measure the load.
- u) **DO NOT** use damaged hoist or hoist that is not working properly.
- v) **DO NOT** use the hoist with twisted, kinked, damaged, or worn wire rope.
- w) **DO NOT** lift a load unless wire rope is properly seated in its groove(s).
- x) **DO NOT** use wire rope as a sling or wrap rope around the load.

- y) **DO NOT** lift a load if any binding prevents equal loading on all supporting ropes.
- z) **DO NOT** apply the load to the tip of the hook.
- aa) **DO NOT** operate unless load is centered under hoist.
- bb) **DO NOT** allow your attention to be diverted from operating the hoist.
- cc) **DO NOT** operate the hoist beyond limits of wire rope travel.
- dd) **DO NOT** use limit switches as routine operating stops unless recommended. They are emergency devices only.
- ee) **DO NOT** use hoist to lift, support, or transport people.
- ff) **DO NOT** lift loads over people.
- gg) **DO NOT** leave a suspended load unattended unless specific precautions have been taken.
- hh) **DO NOT** allow sharp contact between two hoists or between hoist and obstructions.
- ii) **DO NOT** allow the rope or hook to be used as a ground for welding.
- jj) **DO NOT** allow the rope or hook to be touched by a live welding electrode.
- kk) **DO NOT** remove or obscure the warnings on the hoist.
- ll) **DO NOT** adjust or repair a hoist unless qualified to perform hoist maintenance.
- mm) **DO NOT** attempt to lengthen the wire rope or repair damaged wire rope.
- nn) **DO NOT** allow personnel not physically fit or properly qualified, to operate hoist.
- oo) **DO NOT** operate hoists unless hook moves in the same direction as indicated on the push button. If opposite direction occurs, see pre-operation checks, Section II Paragraph 2-4.b.
- pp) **DO NOT** operate hoist unless limit switches are operating properly.
- qq) **DO** avoid operating hoist when hook is not centered under hoist. Avoid side pulls and swinging of load or load hook when traveling hoist.
- rr) **DO** operate hoist within recommended duty cycle and **DO NOT** “jog” unnecessarily.
- ss) **DO** conduct regular visual inspections for signs of damage and wear.
- tt) **DO NOT** operate hoist with hooks that have opened up. See Section V, Paragraph 5-2.f.
- uu) **DO** provide supporting structure that has an appropriate design factor based on the load rating and dead weight of the hoist. If in doubt of the supporting structure’s strength, consult a structural engineer.
- vv) **DO NOT** use hoist in location that will not allow operator movement to be free of the load.
- ww) **DO**, when starting to lift, move the load a few inches at which time the hoist should be checked for proper load holding action. The operation shall be continued only after the operator is assured that the hoist is operating properly and that the load is supported in the center of the base/bowl/saddle of the hook.
- xx) **DO** observe recommended inspection and maintenance procedures.
- yy) **DO** use common sense and best judgment whenever operating a hoist.
- zz) **DO NOT** remove drop lugs. Removal will create an unsafe operating condition.
- aaa) **DO NOT** lift guided loads.

SECTION IV - LUBRICATION

4-1. GENERAL

The lubrication services outlined in Paragraphs 4-3 thru 4-6 should be performed before initial operation of the hoist. The lubrication services outlined in Paragraphs 4-2 thru 4-6 should be performed at regular intervals at least every six (6) months, coinciding with spring and fall seasons is recommended. The reason for this is that on hoists installed outside or in unheated areas a “cold test” oil is required in such (below freezing) climates making seasonal changes necessary.

4-2. CHANGING GEARCASE OIL




Figure 4-1. View of Hoist Showing Location of Name Plates and Oil Plugs

- a) Add 5% solution of Mobilsol A (or equivalent) to the oil and run for a short time. This will clean components and hold particles in suspension for draining.
- b) Remove oil drain plug from bottom of gearcase and drain oil out. Dispose of oil in accordance with local environmental codes.

⚠ WARNING

DO NOT operate hoist with the hoisting rope out of the drum grooves. Such operation may result in damage to the rope guide and rope and could result in the rope breaking. This may result in dropping the load that can cause damage to equipment and injury to operator or other personnel. Hoist rope will remain in the drum grooves during operation under normal operating conditions, however, slack or kinked rope, excessive side pulls, swinging or jerking of load, or similar abuse, may cause damage to the rope guide causing the rope to leave the grooves.

⚠ CAUTION

Avoid skin contact with Mobilsol A. In case of skin contact: dry wipe the skin, cleanse the area with a waterless hand cleaner and follow by washing thoroughly with soap and water.

- c) Reinstall drain plug.
- d) Remove oil level plug from front of gearcase cover.




Figure 4-2. Gearcase Width Illustration

- e) Refill through filler hole to proper level (bottom of oil level plug hole) using GCOH (Paragraph 4-7). The amount of oil required depends on the overall size of the gearcase. Both versions of the "A" Frame hoist utilize the same size gearcase, although their contents differ. To confirm the version of your gearcase refer to Figure 4-2. Your gearcase should have a similar shape to that shown and will measure 10 in width and requires approximately 3 quarts of oil.

4-3. LUBRICATION OF HOISTING CABLE

Hoists are shipped from the factory without an exterior coating of grease on hoisting cable. It is recommended that the cable be thoroughly coated at installation and kept well lubricated with CL (Paragraph 4-7).

4-4. LUBRICATION OF LIMIT SWITCH

Provide a light film of grease MPG (Paragraph 4-7) on bevel gear of rotary geared limit switch.

4-5. LUBRICATION OF GEARED TROLLEY WHEELS AND PINIONS

At installation and periodically, apply grease WG (Paragraph 4-7) to the traverse drive pinions and the gears of the trolley wheels.

4-6. LUBRICATION OF ROPE GUIDE

- a) Maintenance. The rope guide is made of a molded self-lubricated reinforced nylon material. It is lubricated prior to installation at the factory and requires only periodic inspection.
 - (1) Periodically re-grease with MPG (Paragraph 4-7) by applying grease to the leading edge of the guide and rope drum.
 - (2) Every 6 months, the rope guide should be removed per Section V, Paragraph 5-5, cleaned and inspected. When reassembled, the rope guide should be thoroughly greased with MPG (Paragraph 4-7) and the hoist run up and down to lubricate both the drum and the wire rope.

NOTES



4.7 LUBRICANT SPECIFICATIONS		AMBIENT TEMPERATURE		
		-20° to +50° F (-29 to +10°C)	50° to 125° F (10° to 52°C)	125° to 250°F (52° to 121°C)
GCOH	AGMA Lubricant	No. 6	No. 7 EP	No. 7
Gear Case Oil Hoise Gearcase	Viscosity @ 100° F	1335-1632 SUS	1919-2346 SUS	1919-2346 SUS
	Viscosity Index	154	95	158
	Pour Point	-40° F	20°F	-37°F
	Mobil® Oil Corp	Mobil® SHC 632	Mobilgear® 600, XP-460	Mobil® SHC 634
	Shell® Oil Corp	Omala® RL 320	Omala® 460	Omala® RL 460
	Texaco® Inc.	Pinnacle® 320	Meropa® 460	Pinnacle® 460
SG	NLGI Grease	No.1		
Spline Grease	ASTM D217 Worked Penetration	310-340		
	Dropping Point	320°F (160°C)		
	Base	Lithium		
	Mobile® Oil Corp.	Mobilux® EP 111		
WG	Viscosity @ 100° F	25,000 SUS (contains diluent)		
Wheel Gear and Pinion Grease	Mobil® Oil Corp.	Molitic® 375 NC		
	Texaco® Inc.	Crater H®		
CL	No Specification			
Cable Lubricant Wire Rope Lubricant	Amoco® Oil Co.	Amovis® 5-X		
	Mobil® Oil Corp.	Mobilarma® 798		
	Sun® Oil Corp.	Sunoco® Wire Rope Lubricant		
	Texaco® Inc.	Crater A	Texclad® 2	
GO	AGMA Lubricant	No. 1	No. 2	
General Oil General Oiling to Prevent Rusting and Provide Limited Lubrication for Points Not Considered Normal Wear Points	Viscosity @ 100° F	193-235 SUS	284-347 SUS	
	Viscosity Index	60 Min.	60 Min.	
	Pour Point	-20°F (-29°C)	10°F (-12°C)	
	Amoco® Oil Co.	Rykon® Oil 46	American Industrial Oil® 68	
	Mobil® Oil Corp.	Mobil® DTE Oil Heavy		
	Shell® Oil Co.	Rotella® 10W	Rotella® 10W-30	
	Sun® Oil Co.	Sunvis® 932	Sunvis® 968	
	Texaco® Oil Inc.	Rando® Oil 46	Rando® Oil 68	
MPG	NLGI Grease	No.1	No. 2	
Multipurpose Grease Grease Lubricated Wear Points Provided	ASTM Worked Penetration	310-340	265-295	
	Dropping Point	360°F (182°C)	360°F (182°C)	
	Base	Lithium	Lithium	
	Amoco® Oil Co.	Amolith® Grease 1 EP	Amolith® Grease No. 2 EP	
	Mobil® Oil Corp.	Mobilith® AW1	Mobilith® AW 2	
	Shell® Oil Co.	Retinax LC		
	Sun® Oil Co.	Presitge® 741 EP	Sunoco® Multipurpose 2	
	Texaco Oil Inc.	Multifak® EP 1	Multifak® EP 2	
GCOT	AGMA Lubricant	No. 7 or 7C (Compounded)	No. 8 or 8C Compounded	Refer to YALE Hoist Field Service Department for Gearcase Operating Temperatures above 125° F
Gear Case Oil Traverse Gear Case	ISO Viscosity Grade	460	680	
	Amoco® Oil Corp.	Worm Gear Oil	Cylinder #680	
	Mobil® Oil Corp.	Mobil® SHC 643 Synthetic, Mobil® 600W	Mobil® SHC 634 Sythetic, Extra Hecla Super	
	Shell® Oil Co.	Valvata® J460	Valvata® J680	
	Texaco Oil Inc.	Meropa® 460	Meropa® 680	

SECTION V - INSPECTION AND PREVENTIVE MAINTENANCE

5-1. GENERAL

All YALE “Global King” hoists are inspected and tested at the factory. Regular in-service inspection and preventative maintenance programs not only help reduce overall maintenance costs but may also prevent service shutdowns by forewarning of problems that could cause these shutdowns. Regular inspections, periodic minor adjustments, regular cleaning and lubrication and replacement of worn parts can help preserve good performance and operation of your hoist.

Many factors influence the inspection and preventative maintenance program required for your hoist. Frequency and severity of service and material handled, local environmental conditions and various applicable codes are some of the factors that the user must consider to adjust inspection and maintenance program outlined in this section to meet his specific conditions.

The inspection and maintenance intervals outlined in this section are considered a minimum. Recommended in the schedule are minimum inspection and maintenance intervals based on average daily use in a normal environment. Your YALE “Global King” hoist was designed to meet a specific duty classification as described by the FEM “Rules for the Design of Serial Lifting Equipment” and is to be used in accordance with the duty rating identified on the equipment nameplate. For more details regarding hoist duty cycles and average daily use, please reference FEM Section IX, Series Lifting Equipment or the Hoist Duty Classification page in this manual.

Environmental conditions in which the hoist operates are also important considerations for the user, when adjusting hoist inspection and maintenance programs to local conditions. Frequency of inspection and maintenance must be increased if hoist is subjected to severe atmospheric environmental conditions, such as corrosive vapors, extreme heat or cold, cement or dust and other airborne contaminants. The user should carefully consider all environmental conditions and adjust frequency and degree of maintenance for his local conditions. Consult the factory’s Field Service Department for advice regarding unusual environmental conditions.

Various codes also regulate inspection and maintenance programs. Attention must be given to applicable federal standards, OSHA regulations, national standards, state and local codes which may include mandatory rules relating to hoist inspection and maintenance. The user should become familiar with all applicable codes for his area and be guided accordingly.

Listed on the Recommended Inspection and Maintenance Schedule are inspection frequencies and requirements. Perform these inspections regularly as scheduled and additional inspections as may be required for activity, service, and environment of your hoist. The hoist operator must be responsible for determining the operating conditions and severity of service.

Inspection Schedule and Maintenance Report Form.

Shown on page 12 of this manual is a recommended Inspection Schedule and Maintenance Report form that lists various components of the hoist. The form also includes trolley components, runway components, and miscellaneous items. This form is suggested as a guide for written inspection reports. Inspections are recommended each month and should be performed thoroughly enough to inform the hoist user of deficiencies for any item listed. This form does not supersede the Inspection and Maintenance Schedule listed on page 11

of this manual but may be used to record scheduled inspection and maintenance services required.

The user should revise the inspection interval, add additional units or provide a similar form to suit particular conditions that may exist. However, written, dated and signed inspection reports should be maintained particularly on critical items such as hoist hooks, hoisting rope, sheaves, drums and brakes. Periodic review of old inspection reports can point out service life of hoist components, forecasting need for adjustment, repair or replacement of these components.

As a matter of expedience, appointed maintenance personnel inspecting hoist can also take care of minor adjustments, repairs and cleaning, where required. Note column on Inspection Schedule and Maintenance Report form headed Corrective Action and Notes. When corrective action is made during inspection, note condition of part or unit as inspected in appropriate Condition column with a check mark (Ö). Note “during inspection” corrective action taken and date in space provided. In this manner, items requiring further attention will be checked (Ö) without showing corrective action. This will advise the person responsible for hoist operation and safety, or whoever reviews the inspection reports, that deficiencies exist. The designated person will check all deficiencies as listed and re-examine or otherwise determine whether they constitute a safety hazard.

WARNING

Deficiencies may be hazardous to personnel and equipment. Do not operate a hoist having deficiencies unless a designated qualified person has determined that these deficiencies DO NOT constitute a safety hazard.

Written, dated and signed inspection reports for many items are mandatory under OSHA regulations, and many state safety codes.

It is strongly recommended that the Inspection Schedule and Maintenance Report, shown herein, be completed by a qualified person designated with the responsibility for hoist operation and safety or an inspector appointed by this person.

Inspection records can point out the service life of hoist components and help forecast the need for adjustments, repairs, and ordering of replacement parts. File and review these reports after each inspection.

All YALE “Global King” hoists are equipped with a Pulse™ monitor, which is wired into the control circuit in the control enclosure. This equipment consists of a circuit board, a serial communications port, and onboard memory, which will retain data even when the hoist is removed from power. The Pulse monitor takes the “pulse” of the equipment by recording the most recent hoist activities including all normal operation events, motor starts, overcapacity lifts and thermal overload events. In addition, the monitor records the total cumulative operating time and motor starts for the life of the equipment. Each Pulse monitor is programmed with the equipment serial number at the factory.

Data may be downloaded from the monitor, via the serial communications link, by a certified technician. Pulse monitor data may be used to determine equipment usage and to verify that the application does not exceed the hoist duty rating as identified on the equipment nameplate. The data can also be helpful in establishing and scheduling preventative maintenance as well as an aid in troubleshooting the equipment. For additional information refer to the Pulse monitor manual (P/N 11817503) sent with this manual.

INSPECTION SCHEDULE AND MAINTENANCE REPORT

HOIST SERIAL NO. (MFGRS) _____

CUSTOMER CRANE IDENTITY NO. _____

RATED LOAD _____

LOCATION IN PLANT _____

TYPE _____

THIS INSPECTION IS **MONTHLY** ☐ **ANNUAL** ☐

VOLTAGE _____

SEMI-ANNUAL ☐

INSPECTED BY: _____ **DATE** _____

Component, Unit Or Part and Location		* Recommended Inspection Interval			CONDITION (Check column best indicating condition when part or unit is inspected. Use note column to the right if condition is not listed below.)							Corrective Action Notes	
LOCATION	Component, Unit or Part	MONTHLY	SEMI-ANNUAL	ANNUAL	GOOD	ADJUSTMENT REQUIRED	REPAIR REQUIRED (Loose Parts or Wires)	REPLACEMENT REQUIRED (Worn or Damaged)	LUBRICATION REQUIRED (Low Oil or Grease, Rust or Corrosion)	CLEANING OR PAINTING REQUIRED	DATE		
HOIST	Motor	<input type="radio"/>									(Indicate corrective action taken during inspection and note date. For corrective action to be done after inspection, a designated person must determine that the existing deficiency does not constitute a safety hazard before allowing unit to operate. When corrective action is completed, describe and note date in this column.)		
	Motor Brake	<input type="radio"/>											
	Mechanical Load Brake	<input type="radio"/>											
	Overload Clutch	<input type="radio"/>											
	Couplings	<input type="radio"/>											
	Gears, Shafts, & Bearings	<input type="radio"/>											
	Upper Block	<input type="radio"/>											
	Lower Block	<input type="radio"/>											
	Hook & Throat Opening	<input checked="" type="radio"/>		X									
	Hoist Rope	<input checked="" type="radio"/>											
	Rope Drum		<input type="radio"/>										
	Rope Guide		<input type="radio"/>										
	Guards	<input type="radio"/>											
	Limit Switch												
CONTROL STATION OR PUSH BUTTON	Pushbutton		<input type="radio"/>										
	Wiring		<input type="radio"/>										
TROLLEY	Motor	<input type="radio"/>											
	Brake (when so equipped)	<input type="radio"/>											
	Couplings	<input type="radio"/>											
	Gears, Shafts, & Bearings	<input type="radio"/>											
	Frame			<input type="radio"/>									
	Wheels		<input type="radio"/>										
	Bumpers		<input type="radio"/>										
	Guards		<input type="radio"/>										
	Conductors	<input type="radio"/>											
	Collectors	<input type="radio"/>											
RESISTORS	Hoist		<input type="radio"/>										
	Trolley		<input type="radio"/>										
RUNWAYS	Monorail Joints		<input type="radio"/>										
	Monorail		<input type="radio"/>										
	Main Conductors	<input type="radio"/>											
	Main Collectors	<input type="radio"/>											
MISC.	General Condition		<input type="radio"/>										
	Load Attachment Chains	<input checked="" type="radio"/>											
	Rope Slings & Connections	<input checked="" type="radio"/>											
	Change Gearcase Lub.			<input type="radio"/>									
	Grounding Faults		<input type="radio"/>										

*See text for DAILY & WEEKLY REQUIREMENTS. ☒ SIGNED & DATED REPORT REQUIRED – OSHA.
☐ INSPECTION INTERVAL **X** MAGNETIC PARTICLE OR EQUIVALENT EXAMINATION REQUIRED.

Typical Inspection Schedule and Maintenance Report form.
 User must adjust inspection interval and components to suit his individual conditions and usage.

12375gwr

WARNING

Do not operate a hoist having unusual vibrations, sounds, or with anything visibly or otherwise wrong. Danger may be present that the hoist operator cannot see. Determine and correct the cause of unusual conditions and make certain hoist can be operated safely.

5-2. INSPECTION OF LOWER BLOCK

Refer to the Section IX, Figure 9-4.
Lower Block Assembly.

- Check lubrication of all parts. Also lubricate the shank of the hook that passes through the crosshead. If the thrust bearing is removed, apply MPG grease (Section IV, Paragraph 4-7).
- Check each sheave to insure rope groove is smooth and free from burrs, or other surface defects.
- Check each sheave for freedom of rotation; replace bearings if defective.
- Make certain that the spring pin holding the hook nut to the hook is securely in position.
- If hook is equipped with a hook latch or rotational lock, check to determine that they are in good operating condition.
- Check throat opening of the hook. (Refer to Figure 5-2.) It is recommended that upon receipt of the hoist, a measurement be made and recorded of the hook throat opening. OSHA regulations require that the hook be replaced if the throat opening exceeds 15 percent of the original opening, or if the hook is twisted more than 10 degrees from the unbent plane. We suggest that a gage block properly identified to the hoist, similar to the one shown in Figure 5-2, be made for each hook for use in these measurements.




Figure 5-2. Gage Block

- Hooks showing signs of cracks must be replaced. Hooks should be inspected at least once per year using dye penetrants, magnetic particle, or other suitable non-destructive test methods.
- Check wear of the hook, especially at the saddle and replace if worn more than 10% of original dimensions.

5-3. INSPECTION OF UPPER BLOCK

Refer to the Section IX, Figure 9-5.
Upper Block Assembly.

- Check upper block sheaves for wear, damage and freedom of rotation. If sheaves do not rotate freely, disassemble block and inspect bearings. Replace worn or damaged bearings, washers, pins, or sheaves.
- Make certain that all sheaves, bearing and hanger pins are free of foreign material. Bearings without grease fittings are lubricated for the life of the bearing and require no further lubrication.
- Make certain that the rope retention bolts are not bent, loose or otherwise distorted; bolts must have close clearance to sheave flange to keep rope in sheave grooves.

5-4. INSPECTION OF ELECTRICAL CONTROLS

Arrangement of electrical control equipment varies with the type of control, physical space and the optional control features ordered with the hoist.

Note the location in the electrical enclosure of the control circuit fuse, transformer, limit stop switches and the hoist contactors. Trolley contactors and optional hoist and trolley fuses are also located in this enclosure.

Use wiring diagrams furnished with hoist to determine electrical components on your hoist; then determine component location and identity on your hoist.

WARNING

Be certain that main power switch is locked in open position (OFF) before opening hinged control enclosure cover mounted to the counterweight.

- Open hinged control panel enclosure cover mounted to the counterweight and inspect wiring and terminals. Terminals should be securely crimped to wires and insulation sound. Terminal screws should be tight.
- Check condition of contactor assembly, transformer, and upper limit switches.

5-5. INSPECTION OF ROPE GUIDE

- General. The rope guide is intended to help prevent the rope from "back-winding" and to hold the rope in the proper groove. Side pulling and excessive load swing will severely damage the rope guide and must be avoided.

WARNING

Side pulling and excessive load swing will severely damage the rope and rope guide. Failure of these components may result in injury.




Figure 5-3 Rope Guide Assembly

b) Disassembly of "A" Frame Rope Guide. Refer to Fig. 5-3. For further assistance in locating components, refer to the parts list in Section IX.

- (1) Remove socket head cap screws and lock washers (Items 6 and 7). Remove drum frame rod (Item 8).
- (2) Remove shoulder bolts (Item 3) and compression springs (Item 4). The two halves of the rope guide body (Item 1) can now be pulled off the drum separately. When reassembling be sure that the half with the rope slot is on the top half of the drum.

WARNING

Once shoulder bolts are removed, the halves will separate and, if not properly supported, the halves could fall.

- (3) Carefully unhook the rope tensioning spring (Item 5), which is under tension.

WARNING

The rope tensioning spring is under considerable tension; use caution when unhooking to avoid injury.

- (4) Remove the split plastic shroud (Item 2) from the drum. When reassembling the rope guide, be sure the plastic shroud (Item 2) fits snugly in the rope guide body groove.
- (5) Thoroughly clean and inspect all components.
- (6) Follow steps in reverse to reassemble. Be sure to re-grease the rope guide with **MPG** (Paragraph 4-7), after assembling.

5-6. ROPE INSPECTION, MAINTENANCE AND REPLACEMENT

WARNING

Wire Rope improperly handled or abused can create a **SAFETY HAZARD**. Read and comply with inspection, maintenance and replacement information given herein.

a) Inspection. Wire rope on your hoist is one of the most important components requiring frequent inspection and maintenance. All wire ropes will eventually deteriorate to a point where they are not safe and will require replacement. Wire rope should be thoroughly inspected at regular monthly intervals by an authorized person and a determination made when further use of the rope would constitute a safety hazard. Each inspection should include a written dated and signed report of rope condition. Reports should be filed and reviewed each month and any rope deterioration carefully noted. Inspections revealing, but not limited to the following conditions, should cause inspector to question remaining strength of rope and consider replacement. Inspections should take place at the most active sections of the rope, which may be identifiable through visual inspection of rope color. Ropes will wear more quickly in areas that are more frequently in contact with the running sheaves and drum.

- (1) Replace wire rope if the number of visible broken wires exceeds 13 over a length of 6 times the nominal diameter (6d) or exceeds 26 wires over a length of 30d.
- (2) Replace wire rope, if a complete strand has broken.
- (3) Replace wire rope, if rope exhibits swelling, bruises, permanent bends, kinks, crushing, bird-caging or especially heavy wear.
- (4) Replace wire rope, if rope has suffered heat damage from any cause.




Figure 5-4. Correct Method of Measuring Rope

- (5) Rope corrosion and/or rust formation, internal or external.
- (6) Effects from improper lubrication.
- (7) Rope being idle for one month or more due to shutdown or inactivity.

Special attention should be exercised when inspecting rope normally hidden during inspecting procedures.

Please refer to FEM Section IX, Series Lifting Equipment, namely Section 9.661, "Dimensions and Design of Rope Reeving Components" and ISO 4309, "Wire Ropes - Care, Maintenance, Installation, Examination and Discard", for illustrations and definitions when following the above guidelines for rope inspection.

- b) **Maintenance.** Keep rope well lubricated to help reduce internal friction and prevent corrosion. Lubricant, as described in Paragraph 4-3, should be applied as a part of the regular maintenance program. Special attention is required to lubricate sections of rope over equalizing sheaves and other hidden areas.

Avoid dragging ropes in dirt or around sharp objects that will scrape, nick, crush, or induce sharp bends in the rope.

⚠ WARNING

Use only factory-approved rope with swaged wire rope socket.

- c) **Replacement.** When recommended by an authorized inspector, the rope should be replaced. Replacement rope assemblies are shipped from the factory carefully coiled to prevent damage by kinking. Care must be taken to avoid twisting or kinking when uncoiling and handling during reeving.

Before replacing rope, check condition of grooves in sheaves and drums to determine if they are excessively worn.

When first using hoist after rope replacement, break in rope by operating under lighter loads to full travel before applying maximum load.

5-7. ROPE REEVING

- a) **General.** Place reel on stand with shaft through the center of reel so rope can be pulled straight out with reel rotating.

⚠ WARNING

It is imperative that rope reel or coil rotates as rope unwinds. If coil or reel does not rotate the wire will be twisted as it is uncoiled and kinking will result. A kinked rope is unsafe and must be removed from service.

- b) Before removing the old rope, refer to reeving diagram, Figure 5-5. To assist with re-reeving your hoist, refer to the reeving diagram and corresponding paragraph that describes the reeving procedure.




Figure 5-5a. Reeving Diagram - 4 Part Single Reeved.
(Note: Arrow on Drum Indicates Direction of Drum when Lowering.)




Figure 5-5b. Reeving Diagram 2 Part Single Reeved

- c) **Removing old rope.** Please refer to Section IX to assist in locating components referred to in the following paragraphs.

- (1) Lower the lower block to a scaffold 6 to 7 feet below hoist to relieve tension on wire rope. (Lower block may be lowered to the floor if desired; however, to handle less weight and for ease of reeving, adequate scaffold below the hoist is recommended.)

⚠ CAUTION

Be certain all personnel are clear of hoist as components, hardware, and wire rope are removed from hoist.

- (2) Remove the cap screws and hex nuts that retain the lower block sheave covers. Remove covers.
- (3) Remove retaining rings from lower block sheave pin.
- (4) Slide out lower block sheave(s) and remove wire rope.
- (5) Remove two (2) rope retention bolts and nuts from the upper block yoke, as needed.
- (6) Remove one retaining ring on upper block to allow removal of upper block sheave pin.

- (7) Securely grasp the upper block sheave before carefully sliding the sheave pin out. Note that two spacers will also be released as the pin is removed.
- (8) Remove wire rope from sheave.
- (9) Remove retaining ring(s) and washer from dead end anchor pin. Securely grasp the swaged wire rope before removing the anchor pin.
- (10) Remove rope guide per Section V, Paragraph 5-5.
- (11) Make certain all personnel are clear of hoist and operate hoist "DN" to completely unwind all wire rope from drum. Stop hoist so all (3) rope clamps are accessible. Remove rope clamps and wire rope from drum.

⚠ WARNING

Winding rope on rope drums with power can be hazardous. Keep hands safe distance from drum; wear gloves and use extreme care when winding rope.

d) Installing new rope.

- (1) Thread rope to drum from trolley frame side then secure with rope clamps as follows:
 - (a) Make sure that the rope clamp is orientated such that the clamp grooves capture and fully seat the rope in the drum grooves. The clamps are designed for use specifically with the 6.4mm wire rope that was supplied with your "A" Frame hoist.
 - (b) With the rope lying in the bottom of the drum groove, begin by tightening the rope clamp at the tail end of the rope. Torque the "A" Frame clamps to 12-15 ft.-lbs. (16-20 N-m).
 - (c) Applying tension to the rope and keeping it properly seated in the drum groove, install the remaining two clamps to the specified torque above.
- (2) With all personnel clear of hoist - TURN ON POWER.
- (3) Operate hoist "UP" guiding six (6) wraps of new rope into drum grooves with gloved hand.
- (4) Reinstall rope guide over rope in rope drum grooves as shown in Figure 5-3a. & 5-3b. and outlined in Section V, Paragraph 5-5. Continue lubricating as rope is spooled onto the drum until about 24'-0" remain unwound.
- (5) With outer lower block covers removed, thread the wire rope through the sheaves of the upper and lower block as shown in Figures 5-5a and 5-5b.
- (6) Attach swaged rope end to the dead end anchor pin and fasten with the retainer rings provided with the hoist.
- (7) Replace the lower block sheave covers.
- (8) Lubricate cable per Paragraph 4-3.

⚠ WARNING

The hoist must be removed from service and placed on the ground for any maintenance that requires removal of the output shaft assembly or drum.




Figure 5-6. Drum Frame & Geared Limit Switch

5-8. INSPECTION OF ROPE DRUM AND SHAFT

- a) To remove the rope drum, remove the rope guide and hoisting cable, as outlined in Section V, Paragraphs 5-5. and 5-7.c., respectively.
- b) Remove the geared limit switch or disconnect the wires so that the electrical cable will not inhibit removal of the drum. (see Figure 5-6).
- c) Remove the hoist from the beam, place it on the ground and provide adequate means to support the drum before removing the frame rod cap screws and rods at the outboard end drum frame (see Figure 5-6).
- e) The hardware attaching the drum frame to the hoist and trolley frame may then be removed.
- f) Keeping the drum level, remove the drum from the splined output shaft at the gear case end.
- g) Inspect the gearcase output shaft and drum splines for wear.
- h) Before re-assembling, by reversing above instructions, make sure to apply a liberal amount of SG (Paragraph 4-7) spline grease to both the output shaft and drum splines. Torque "A" Frame drum mounting bolts to 60-80 ft.-lbs. (81-108 N-m).

5-9. INSPECTION OF HOIST GEARING




Figure 5-7. Hoist Gear Case Assembly

- a) **General.** The hoist gear case is a triple-reduction, splash lubricated, vertically split, cast aluminum case and cover. A helical gear train provides smooth and quiet hoisting operation. The gear shafts are supported with ball and roller bearings housed in the back of the case and in the cover. The input pinion is integrated onto the motor shaft. An oil seal housed in the gear case at the motor input seals the motor shaft as it passes into the gear case. Since the entire motor shaft is submerged in oil, anytime the motor is removed, the oil must be drained from the gear case. All pinions are integral with their shafts while the gears are keyed and pressed onto their shafts, with exception of the integral output shaft. The output shaft passes through an oil seal in the back of the gear case and drives the drum by means of a crowned spline. One end of the rope drum is supported on this output shaft.

- b) **Inspection and Disassembly.**
Gearcase. (See Figure 5-7.)

- (1) Lower hook block to the floor and relieve all load from ropes.
- (2) Make sure power to hoist is off and locked out.

WARNING

Before disassembly, prevent rope drum from free spinning by wedging drum in place with a block of wood, and resting lower block on work surface so all weight is off rope drum. Rope may also be removed from hoist drum.

- (3) Drain the oil from the gear case per Section IV, Paragraph 4-2.
- (4) On the "A" Frame hoist, the bolts supporting the gearcase are installed through tabs on the outside of the housing and do not pass through the gearcase cover. These bolts are not to be removed, unless the entire gearcase assembly is being removed from the hoist.
- (5) Provide adequate means to support the gearcase cover. Remove the smaller socket head cap screws and lockwashers holding the cover to the gearcase. Carefully draw the cover directly away from the gearcase, as damage to this surface will prevent the gasket from sealing properly. If needed, lightly tap on the top and bottom cover tabs to release. As the cover is removed,

ensure that all gear and shaft assemblies remain in the case and are fully supported by the gearcase bearings.

WARNING

If output shaft assembly is pulled out of the gear case with the cover, it will disengage from the drum allowing the drum to drop. Be certain all shaft assemblies stay in the case.

- (6) If it is necessary to remove the output shaft assembly from the gear case, the rope drum must first be removed from the hoist. See Section V, Paragraph 5-8. Only once the output shaft is free of the rope drum, can the output shaft assembly be safely removed from the gearcase. Provide an adequate means to support this shaft and gear assembly before removing, as it is heavy. The "A" Frame gear assembly weighs 14 lbs.

WARNING

The hoist must be removed from service and repaired on the ground for any maintenance that requires removal of the output shaft assembly or drum.

- (7) The pinion shaft and gear assemblies may be removed as necessary.
- (8) Inspect all gears, pinions, bearings, and the output shaft spline for wear, pitting, or mechanical damage. Replace the gearcase assembly, as necessary. Thoroughly clean the output shaft external spline teeth before reassembly.
- (9) Assembly is opposite of removal. Use a new gasket. Do not attempt to assemble the cover to the gear case without a gasket, as the spacing between bearings will be reduced. Severe damage to the hoist will occur if no gasket or the wrong gasket is used. Refill gear case with new lubricant per Section IV, Paragraph 4-2 before use. Using SG (Paragraph 4-7), grease the spline teeth on the output shaft before reinstalling rope drum.
- (10) Test hoist per Section V, Paragraph 5-14 to ensure proper lubrication.

Hoist Motor.

- (1) Lower hook block to the floor and relieve all load from ropes.
- (2) Make sure power to hoist is off and locked out.
- (3) Drain the oil from the gear case per Section IV, Paragraph 4-2.
- (4) Disconnect the wiring and conduit from the motor junction box.
- (5) Provide a means to support the hoist motor. The "A" Frame S4 hoist motor weighs approximately 70 lbs. and the S2 hoist motor weighs approximately 50 lbs. The motor must be adequately supported and held horizontally while removing and installing, to avoid input seal damage.
- (6) Once the motor is properly supported, remove the hardware fastening it to the gear case. Carefully withdraw the motor horizontally straight out from the gear case. Do not tip or move the motor from side to side.

- (7) Replace the motor shaft seal using an appropriate seal driver. It is recommended that a new seal be installed each time the motor is removed from the case.

IMPORTANT!

- (8) Before reinstalling the motor, pack the gear teeth with MPG grease (Paragraph 4-7) and wrap the gear teeth with a number of layers of Teflon tape to protect the seal lip from being damaged by the gear teeth. Coat the seal lip and the motor shaft with MPG grease.

NOTICE

Failure to use a factory replacement seal will cause premature seal failure due to specific lip material requirements that must be met.

- (9) Install the motor to the gear case. The motor shaft must be in line with the seal bore and perpendicular to the mounting surface before attempting to insert the shaft through the seal. The motor shaft must remain horizontal and not rock up and down or side-to-side while installing the motor or seal damage will occur. It may be necessary to rotate the rope drum slightly to align the gear teeth to mesh with the teeth on the motor shaft. Ensure that the motor seats properly into the rabbet fit machined in the gear case. Fasten the motor to the gear case.
- (10) Reconnect the conduit and power leads to the motor. See Section VIII and refer to the specific wiring diagrams shipped with your hoist.
- (11) Refill gear case with lubricant per Section IV, Paragraph 4-2.
- (12) Test hoist to ensure proper operation per Section V, Paragraph 5-14.

5-10. INSPECTION OF MOTOR BRAKE AND ACTUATING MECHANISM

(1) ABM Motor Brake

- a) General Operation. The hoist brake is an electro-magnetically released, spring set non-adjustable brake. Torque is generated by compressing a friction disk between the stationary motor end bell and the spring loaded brake armature. The friction disk is fixed to and rotates with the motor shaft. When the magnet coil is energized, the armature plate is pulled across the air gap. The friction disk is carried by a splined hub that permits axial movement when the brake is released. This axial movement releases both sides of the friction disk from their mating stationary surfaces and allows the friction disk to rotate freely when the brake is energized. When power is removed from the magnetic coil, the compression springs push the armature against the friction disk and the other side of the friction disk against the motor end bell generating the torque necessary to stop the hoist machinery and hold the load.

It will be necessary to compensate for the friction disk wear when a greater amount of hook movement (drift) is noticed when stopping. There is no torque adjustment of the brake. Friction disk wear can only be compensated for by resetting air gap.




Figure 5-8a. ABM Motor Brake

b) Friction Disk Inspection and Air Gap Adjustment.

- (1) Lower hook block to the floor and relieve all load from ropes.
- (2) Make sure power to the hoist is off and locked out.

WARNING

Check to be certain main power switch is locked in open position (OFF), before removing fan shroud.

- (3) Remove the four (4) bolts attaching the fan shroud to the motor and remove the fan shroud. See Figure 5-8.
- (4) Carefully roll the large O-ring from the groove over the air gap back toward the magnet body. Do not excessively stretch this O-ring.
- (5) Measure the air gap using feeler gages. If the air gap exceeds the maximum value shown in Table 5-1a, the air gap must be reset.
- (6) To measure the thickness of the friction disk, it is necessary to remove the brake body from the motor end bell. Remove the three (3) brake mounting bolts and draw the brake body away from the friction disk. Carefully set the brake body down on the motor shaft directly in front of the fan. Draw the friction disk away from the end bell and measure the thickness across the friction surfaces. If the friction disk thickness is less than the minimum shown in Table 1, it must be replaced. See Section IX, Figure 9-8. If the friction disk thickness is within the allowable, reassemble the brake body to the motor end bell and torque the mounting bolts to the value shown in Table 5-1a. Whenever the friction disk is replaced, it is necessary to reset the air gap.

Hoist	"A" S2	"A" S4
Mounting Bolt Torque	7.5 ft.-lbs. (10 Nm)	7.5 ft.-lbs. (10 Nm)
Minimum Air Gap	0.012 in. (0.3 mm)	0.012 in. (0.3 mm)
Maximum Air Gap	0.031 in. (0.8 mm)	0.035 in. (0.9 mm)
Minimum Brake Disk Thickness	0.335 in. (8.5 mm)	0.374 in. (9.5 mm)

Table 5-1a. Motor Brake Data (ABM Motor Brake)

(7) To reset the air gap, begin by releasing the (3) mounting bolts 1/2 turn. Turn the hollow spacer bolts into the magnet body approximately 1/4 turn. Retighten all three mounting screws. Measure the air gap at a minimum of three places around the circumference. Threading the hollow spacer bolts into the magnet body will decrease the air gap, while backing these spacer bolts out of the magnet body will increase the air gap. Repeat this step, as necessary, until the required air gap is achieved. The air gap must be the same all the way around the brake. Once the air gap is correct, torque the mounting bolts to the value shown in Table 5-1a.

(8) Replace the large O-ring over the air gap and reassemble the fan shroud to the motor.

(9) Test hoist per Section V, Paragraph 5-14 to ensure proper brake operation.

c) **Brake Disassembly.**

(1) Lower hook block to the floor and relieve all load from ropes.

(2) Make sure power to the hoist is off and locked out.

(3) Remove the four (4) bolts attaching the fan shroud to the motor and remove the fan shroud. See Figure 5-8.

(4) Remove the snap ring behind the plastic fan. Carefully remove the fan and key from the motor shaft. Remove the snap ring in front of where the fan was mounted.

(5) Disconnect the two wires from the terminal block on the magnetic body.

(6) Remove the three mounting bolts that attach the brake body to the motor end bell and remove the brake body from the motor. Remove the friction disk from the motor shaft.

(7) Clean and inspect all components and working surfaces. Replace all damaged or worn components as necessary. Measure friction disk thickness and replace if less than the minimum thickness shown in Table 5-1.

d) **Brake Re-assembly.**

(1) Install the friction disk on the splined hub. The friction disk must slide on the splined hub and seat against the end bell of the motor.

(2) Install the brake body to the motor end bell using the three (3) mounting bolts. The air gap must be reset as described in Section V, Paragraph 5-10.b. Torque the mounting bolts to the values shown in Table 5-1. Install the large O-ring in the groove over the air gap. Ensure this O-ring is not pinched in the air gap.

(3) Connect the brake leads to the terminal block on the brake body.

(4) Install the forward fan mounting retaining ring and install the fan. Install the rear retaining ring. Install the fan shroud and bolts.

(5) Test hoist per Section V, Paragraph 5-14.




Figure 5-8b. MGM Motor Brake

(2) **MGM Motor Brake**

a) **General Operation.** The hoist brake is an electro magnetically released, spring set adjustable brake. Torque is generated by compressing a friction disk between the stationary motor end bell and the spring loaded brake armature. The friction disk is fixed to and rotates with the motor shaft. When the magnet coil is energized, the armature plate is pulled across the air gap. The friction disk is carried by a splined hub that permits axial movement when the brake is released. This axial movement releases both sides of the friction disk from their mating stationary surfaces and allows the friction disk to rotate freely when the brake is energized. When power is removed from the magnetic coil, the compression springs push the armature against the friction disk and the other side of the friction disk against the motor end bell generating the torque necessary to stop the hoist machinery and hold the load.


It will be necessary to compensate for the friction disk wear when a greater amount of hook movement (drift) is noticed when stopping. There is no torque adjustment of the brake. Friction disk wear can only be compensated for by resetting air gap.

Verify that all motor and brake supply terminals are properly tightened to the terminal board as well as the earthing terminal to the motor frame. As a result of normal wear of the brake disc lining, check that the air gap does not exceed the values shown on table 1. Please note that the brake linings wear is greater during the run-in. (few thousands stops). For the air gap adjustment, follow the instructions given into the paragraph "Air Gap Adjustment". Check the wear on both friction surfaces of the brake disc (on one side only for BAPV series) to be sure that their thickness is not less than 2 mm. Verify also that there are no damages on disc surfaces and in particular, in the hub toothing. (For replacement, refer to the paragraph "Brake Disc" Replacement"). For those brake disc with rivets on disc lining verify that braking surface has not reached the rivets; moreover check

that no play should be between the brake disc and the brake disc hub in correspondence of the hub nails. Verify periodically that the braking torque is suitable. If needed, proceed to its adjustment as stated in the paragraph "Braking Torque Adjustment". Verify regularly the brake adjuster (19-42) wear conditions and their steady fastening on the rear cover brake Figure 5-8b. MGM Motor Brake surface (17). All brake assembly components, in particular the brake disc (23, 39-41 for BAF series, 45 for BAPV) and the brake adjusters (19, 42 for BAF-BAPV series) are subject to wear. In consideration of safety it's needed to replace them periodically. The replacement frequency comes from the motor duty (number of start/stop, applied moment of inertia, environment conditions and so on), we recommend however to replace them at least every 18 months. Periodically check and verify the shaft splines wear, exactly where the disc slides.

Braking Torque Adjustment. The brake torque is proportional to the spring (18) compression. The compression of the springs must be as uniform as possible. Spring height "H" must be maintained to ensure proper brake torque. As the friction disc wears, the spring height and air gap must be adjusted. To prevent damage to the brake, do not over compress the springs. If the brake coil (25) is not able to call the brake moving element (24) back with a quick stroke and keep it attracted without vibrations, verify the exact air gap adjustment and if this inconvenience still persists, loosen the locknut (20) and try it again until desired functioning is obtained. After every intervention please verify that "H" Dim is correct. Never exceed the maximum braking torque value stated on the motor name plate. It's recommended to avoid adjusting the braking torque to values lower than 30% of the maximum value.

Brake Disc Replacement. Loosen the rear nut (27), remove the end cover (26) and unscrew the locknuts (22). Take off the brake coil (25) from the brake adjusters (19), remove the nuts (20-21) and the springs (18). Remove the brake moving element (24) sliding it through the brake adjusters (19). Take off the old brake disc (23) and put in the new one. For re-assembling, proceed backwards. We recommend that the new brake disc must be handled with clean hands, because even a small trace of grease will decrease the braking performance and also increase noise. In the BAF series otherwise than in the BA series there are 2 brake discs (39-41) with an intermediate brake moving element (40) in between. After the brake coil (25) replacement, proceed to the air gap adjustment (see the pertinent paragraph). For the flywheel (45) replacement on the BAPV series, follow up the specific instructions.



Brake Coil Replacement. Loosen the rear nut (27), remove the end 5-11. **INSPECTION OF HOIST TRAVERSE DRIVE cover (26),** disconnect the brake coil (25). Unscrew the locknuts (22) and pull off the brake coil (25) from brake adjusters (19). Reassemble the new brake coil on the brake adjusters (19) and reconnect the electrical connectors. Pay attention to place the electrical connectors in the right position so that to allow their insertion. Before reassemble the end cover (26) and the nuts verify that the connections and relative cables are properly tightened. Proceed with the air gap adjustment as stated in the respective paragraph. Verify that the brake coil functions correctly; when the brake is energized, the brake coil (25) should attract the brake moving element (24) with a quick stroke, and hold it without any vibration or noise. In case of any vibration, check that terminal connectors are coupled correctly and tightly.

Air Gap Adjustment.

The air gap $\ast(60)$ i.e. the distance between the two magnetic cores of the brake coil (25) and the brake moving element (24), must be as shown on Table 5-1b. It's strongly unadvisable to exceed these values in order to avoid vibrations of the brake moving element, prominent noise, the burning of the brake coil or the brake assembly damaging. It's advisable to check periodically the air gap, because the wear of the brake disc linings, it tends to increase. Please note that the brake linings wear is greater during the run-in (few thousand stops). In order to set the air gap back to the required value, operate on the nuts (21-22) to obtain the brake coil forward displacement towards the brake moving element (24). It's strongly recommended to avoid to tighten the locknut (22) located on one brake adjuster (19, 42 for BAPV-BAF series motors) before having completed the positioning of the brake coil (25) on all the brake adjusters. Therefore don't regulate the position of the brake coil adjusting the nut (21) on one brake adjuster, if previously you didn't loose the locknuts (22) on all the brake adjusters (19, 42 for BAPV-BAF series motors). This wrong operation could stress the air gap adjusters. Please verify that the air gap is uniform. The air gap must be uniform to guarantee the right working and avoid mechanical stresses due to a wrong alignment. When the air gap adjustment has been settled, the locknuts (22) should be tightened. For brake assembly with 6 brake adjusters (19, 42 for BAPV-BAF series motors), as first step regulate the brake coil position only on three brake adjusters at 120 by the nuts 21-22. After having adjusted the position on these 3 brake adjusters, to complete the operation go on with the other 3 brake adjusters and first bring the air gap adjusting nuts (21) close to the brake coil and then tighten the locknuts (22). When the operations has been settled, verify that the air gap is uniform and the nuts (21-22) are tightened.

***Note:** On MGM Motor Brake spring height is set first then air gap.

Hoist	"A" S2	"A" S4
Brake Adjuster Stud Torque	N/A	15.49 ft.-lbs. (21 +/-2 Nm)
Minimum Air Gap	N/A	0.012 in. (0.3 mm)
Maximum Air Gap	N/A	0.024 in. (0.6 mm)
Minimum Brake Disk Thickness	N/A	0.079 in. (2 mm)
Spring Height "H"	N/A	15 mm

Table 5-1b. Motor Brake Data (MGM Motor Brake)

5-11. INSPECTION OF HOIST TRAVERSE DRIVE




Figure 5-9. Traverse Drive Arrangement

- Ensure that the hoist is properly fitted to the beam. The hoist must be centered on the beam with clearance between the sides of the bottom of the beam flange and the inside faces of the wheel flanges. Proper clearance must exist along the entire length of beam that the hoist can traverse. An amount of 3/32 to 1/8 inch clearance per side is recommended for a total of 3/16 to 1/4 inch wider than the beam flange. If too little or too much clearance is determined, adjust trolley per Section II, Paragraph 2-2.
- Inspect wheel treads, flanges, and gear teeth for wear. Check for adequate lubrication (**WG**, Section IV, Paragraph 4-7) on the wheel gear and pinion mesh. Check wheel bearings for any signs of wear, including rough rotation and signs of lubricant leakage. Replace all damaged or missing items. Wheels must always be changed in opposing pairs and drive wheels should be changed when the drive pinions are replaced.

NOTICE

Ensure that the cross shaft is properly positioned and locked into place by means of the setscrews. Failure to do so may allow the drive shaft to contact the hoist gearcase.

- Examine the drive pinions, cross shaft, and cross shaft bearings. Check pinions for gear tooth wear and proper alignment with wheel gear. A spacer washer between the cross shaft bearings and the pinion aligns the gear mesh. Set screws hold the pinions and spacer washers tight against the bearings. Verify that the setscrews are tight on the cross shaft. If it is necessary to adjust or reset the pinions, verify that the cross shaft surface is free of mechanical damage and oil before tightening the setscrews. Drive pinions must be replaced as sets and should be replaced along with the drive wheels. The cross shaft bearings are sealed for life and should be replaced at any sign of mechanical wear or lubricant leakage.

When hoists are adjusted or repaired in the field, all set screws must return to the original settings from the manufacturer. This is done by following the below instructions:

- Apply Loctite 242 to the threads and install the setscrews back into the proper location
- Tighten setscrews for the traverse pinion gear down onto the key and shaft to 70 in-lbs before beginning the use of the hoist.

- Inspect the traverse gearbox and motor. Look for signs of rough operation, mechanical damage or lubricant leaks. Inspect the reducer and driving pinion for wear. Verify that all hardware that mounts the reducer to the trolley frame and the motor to the gear reducer are all present and tight. Replace and tighten as necessary. The factory recommends complete replacement of the traverse gearbox. However, gearbox service may be available from your local authorized YALE repair center.

For the trolley gear reducer, the key must be captured in the keyway between the 2 setscrews. The setscrews are located on each side of the trolley gear reducer. The key will float in the keyway between the setscrews. Do not tighten the setscrew down to the keyway. Screw the setscrew down until the setscrew is flush with the outside of the collar.

5-12. TESTING BLOCK OPERATED LIMIT SWITCH

- General.** The optional block operated limit switch is a secondary upper limit switch actuated when the lower block contacts the actuator rod. The rotary-gear limit switch (screw type limit switch) is the primary upper limit switch and must be temporarily bypassed to allow the block operated limit switch to be tested.
- Procedure.** Remove load from the hook. To disconnect the geared limit switch, refer to Figure 7-2. Remove the limit switch cover then loosen the two (2) screws holding the locking plate in place. Allow the locking plate to slide down and disengage from the adjustment discs. Do not rotate the adjustment discs.

The block operated limit switch may now be tested by slowly and carefully raising the hook until the limit switch rod contacts the lower block. If the hook does not stop when the limit switch rod is lifted, immediately release the pushbutton before damage to your hoist occurs. If the block operated switch functions properly, proceed by testing in the same manner with rated load on the hook. Once it has been determined that the block operated limit switch is functioning properly, the geared limit switch must be reconnected and tested.

Position the lower block three inches (3") below the point where the block operated limit switch is activated. The geared limit switch shall be reconnected by sliding the locking plate back into position ensuring slots on adjustment discs are fully engaged and tightening locking plate screws to 4 in-lbs. (See Figure 7-2). The geared limit switch must then be tested.

Test the geared limit switch by raising the lower block until it stops. Ensure that the geared limit switch stopped the hoist before the block operated limit switch was activated. If this is not the case, see Section VII, Paragraph 7-3 for adjusting the geared limit switch. Replace geared limit switch cover when testing and adjusting is complete.

5-13. TESTING OVER-CAPACITY LIMIT SWITCH

The over-capacity limit switch is provided as standard equipment on YALE "Global King" hoists. This switch is integral to the wire rope dead end assembly and is factory preset to prevent over-capacity lifts. This device is preset at the time of hoist inspection to prevent the lifting of loads weighing 125-150% of rated capacity.

CAUTION

Damage to the hoist may occur if the block operated limit switch fails during testing.

Damage can be avoided by immediately releasing the pushbutton once the lower block has traveled through the limit switch weight.

WARNING

Check limit switch operation carefully, without load, before placing hoist in service. If misadjusted, **SEVERE DAMAGE AND/OR A DROPPED LOAD COULD RESULT**. Allow 3" for hook drift in both directions. Never allow less than two (2) complete wraps of rope on drum with hook in lowest position.

To test the function of the over-capacity limit switch, apply 125% of the rated capacity to load hook. If hoist is capable of lifting the load, then actual switch setting may be higher than necessary and needs to be adjusted. If hoist cannot lift load, then the switch setting is correct. Refer to SECTION VII, Paragraph 7-4 for information regarding the adjustment of the limit switch setting

5-14. TESTING HOIST

- a) General. Testing shall be performed in accordance with FEM Section IX, Series Lifting Equipment, namely Section 9.811 "Specification for rope and chain hoists", and this manual. Before placing hoist in service, hoist should be tested to insure safe operation, when hoist has been disassembled and reassembled. To test, suspend hoist from an overhead supporting member of sufficient strength to support the weight of the hoist and the rated load. Connect hoist to power supply as shown on hoist nameplate and perform the checks listed in b) and c) below.
- b) Check hoist as outlined in PRE-OPERATION CHECKS, SECTION II, Paragraph 2-4.
- c) Check hoist with rated load.
 - (1) Attach rated load to lower hook.
 - (2) Depress "UP" push button and raise load. When push button is released, hoist should stop immediately and hold load at that level.
 - (3) Depress "DN" push button, lower load a short distance and release button. Hoist should stop immediately and hold load at that level.

NOTE:

If load drifts downward slowly in step 2 or 3 above, motor brake requires adjustment - see Motor Brake Adjustment - SECTION VII, Paragraph 7-1.

SECTION VI - TROUBLESHOOTING

6-1. GENERAL

This section contains possible causes and solutions to common hoist problems. Please attempt to remedy your hoist problems by following these steps, before contacting the factory.

Whenever servicing electrical components, be sure to shut off and lock out power following proper lockout/tagout procedures.

WARNING

Working in or near exposed energized electrical equipment presents the danger of electric shock.

TO AVOID INJURY:

DISCONNECT POWER AND IMPLEMENT LOCKOUT/TAGOUT PROCEDURE BEFORE REMOVING COVER OR SERVICING THIS EQUIPMENT.

SECTION VI - TROUBLESHOOTING

TROUBLE	PROBABLE CASE	REMEDY
6-1. Hoist Will Not Operate	a. No power to hoist	a. Check switches, circuit breakers or fuses and connections in power supply lines. Check power collectors.
	b. Wrong voltage	b. Check voltage required on motor data plate against power supply.
	c. Loose or broken wire connections in hoist electrical system	c. Shut off and lock out power supply; remove electrical cover on hoist and check wiring connections. Also check connections in push button station and limit switches.
	d. Contactor assembly not functioning	d. See that necessary jumper wires are properly installed. Verify that the contactor armatures are free to move. If binding occurs, replace contactor. Check for burned out contactor coils.
	e. No control voltage	e. Check transformer fuse. If blown, check for grounding and/or shorts in the push button station. Check the transformer coil for signs of overheating. Replace transformer if burned out. Verify the transformer secondary is the same voltage as the coils to which it is connected.
	f. Motor burned out	f. Replace motor. Check input power supply. Check hoist motor connections.
	g. Reverse phasing on three-phase hoists	g. Check phase protection device (PPD), if amber LED is steady; interchange any two power supply line leads per Section II, Paragraph 2-4.b.
6-2. Hook Moves in Wrong Direction	a. Reverse phasing on three-phase hoists	a. Check PPD, if green LED is steady; interchange any two sets (each winding) of motor power leads.
	b. Hoist wired incorrectly	b. Check wiring connections with appropriate wiring diagram.
6-3. Hook Will Raise But Not Lower	a. Lower electrical circuit open	a. Check for loose connections. See that necessary jumper wires are properly installed on contactor.
	b. Contactor assembly not functioning	b. See that necessary jumper wires are properly installed. Verify that the contactor armatures are free to move. If binding occurs, replace contactor. Check for burned out contactor coils.
	c. Down, push button inoperative	c. Check push button contacts and wires.

SECTION VI - TROUBLESHOOTING

TROUBLE	PROBABLE CASE	REMEDY
6-4. Hook Will Lower But Not Raise	a. Excessive load	a. Reduce loading to rated load of hoist, as shown on nameplate.
	b. Hoist electrical circuit open	b. Check for loose connections. See that necessary jumper wires are properly installed on contactor.
	c. Contactor assembly not functioning	c. See that necessary jumper wires are properly installed. Verify that the contactor armatures are free to move. If binding occurs, replace contactor. Check for burned out contactor coils.
	d. Up, down button inoperative	d. Check push button contacts and wires.
6-5. Hoist Will Not Lift Rated Load	a. Low voltage	a. See that power supply current is the same voltage listed on motor data plate. Check hoist motor connections. Check size of power supply lines.
6-6. Hoist Motor Overheats	a. Excessive load	a. Reduce loading to rated load as shown on nameplate.
	b. Excessive duty-cycle	b. Reduce frequency of lifts or amount of jogging.
	c. Wrong voltage or frequency	c. Check current rating on motor data plate against power supply. Check hoist and inspect for defective, worn or damaged parts.
	d. Defective motor or worn bearings in hoist frame	d. Disassemble hoist and inspect for defective, worn or damaged parts.
	e. Brake not adjusted properly	e. Adjust brake per Section VII, Paragraph 7-1.
6-7. Load Drifts Excessively When Hoist Is Stopped	a. Excessive load	a. Reduce loading to rated load, as shown on nameplate.
	b. Motor brake not holding	b. With No Load, check hoist for drift. If drifting is excessive, inspect motor brake (Section V, paragraph 5-10) and adjust as outlined in Section VII, paragraph 7-1.
6-8. Hoist Operates Intermittently	a. Collectors make poor contact	a. Check collectors for free movement of spring arm, weak spring or electrical connections.
	b. Loose connections	b. Check all wiring for loose connections.

SECTION VII - ADJUSTMENTS

7-1. MOTOR BRAKE ADJUSTMENT

These brakes are designed so that adjustment is seldom required. If, after a period of service, the load hook “drifts” downward more than usual for your hoist before coming to a stop, the motor brake may require adjustment to compensate for brake disc wear.

WARNING

Check to be certain main power switch is locked in open position (OFF) before removing brake cover.

Refer to Figure 5-9 and proceed as outlined in Section V, Paragraph 5-10.


7-2. BLOCK OPERATED LIMIT SWITCH ADJUSTMENT

The block operated limit stop is minimally adjustable and designed to stop the lower block at the safest high point of travel to eliminate any possibility of double-blocking. When the safest high point is reached, the limit switch automatically stops hook travel. If the block switch is not tripping after contact with the lower block body, loosen the limit switch hub retaining screw and rotate the hub and rod downward to ensure earlier contact. Retighten and test, repeat as needed until switch functions properly.

7-3. GEARED ROTARY LIMIT SWITCH ADJUSTMENT

The geared rotary type limit switch is standard equipment and is located on the drum end opposite the gearcase end.

This limit switch has a rotary screw driven by a gear reduction that is coupled to the end of the drum shaft. Adjustment discs operate the contacts of separate switches, one for the hoisting circuit and one for the lowering circuit. The switch assembly must be wired in accordance with the appropriate wiring diagram, which is shipped with the hoist. Instructions for adjusting limit switch are inside cover and are repeated below (see Figure 7-2).



**Figure 7-2. Screw-Type Limit Switch Adjustment
(Wires Not Shown for Clarity.)**

WARNING

Be certain that electrical power supply is OFF and locked in the open position before removing limit switch cover.

- Remove four screws and lift off switch cover.
- Loosen locking plate screws. Slide locking plate away from adjustment disc.
- Turn proper adjustment disc (right for up, left for down) toward switch to reduce hook travel or away from switch to increase hook travel.
- Slide locking plate back into position ensuring slots on adjustment discs are fully engaged, tighten locking plate screws to 4 in-lbs.
- Replace cover.
- Carefully check limit switch operation without load before placing hoist in service. If misadjusted, repeat steps above. Allow 3" for hook drift in both directions. Never allow less than two (2) complete wraps of rope on drum with hook in lowest position.

WARNING

Check limit switch operation carefully, without load, before placing hoist in service. If misadjusted, SEVERE DAMAGE AND/OR A DROPPED LOAD COULD RESULT. Allow 3" for hook drift in both directions. Never allow less than two (2) complete wraps of rope on drum with hook in lowest position.

Provide a light film of **MPG** grease (Paragraph 4-7) on gear of both limit switches.

7-4. OVER-CAPACITY LIMIT SWITCH ADJUSTMENT

The over-capacity limit switch is standard equipment and is integrated into the wire rope dead end assembly (see Figure 7-3). The device is designed to prevent overloading of the equipment, but is not intended to be used as a load-measuring device.

The limit switch is factory preset to prevent the lifting of loads weighing 125-150% of rated capacity. At times, it may be necessary to adjust the limit switch setting.




Figure 7-3. Over-Capacity Limit Switch

To adjust the limit switch setting, simply loosen the locking nut (see Figure 7-3) and then either loosen or tighten the adjustment bolt into the overload base to achieve the desired setting. Loosening the adjustment bolt will increase the load required to trip the limit switch plunger while tightening will reduce this setting. Only very small adjustment is required. Adjusting the limit switch setting to increase the capacity limit beyond 125% is not permitted.

7-5. SHORTENING OF PUSHBUTTON CABLE

WARNING

Be certain that electrical power supply is OFF and locked in the open position before attempting shortening of push button cable.

- a) Loosen screws at cable connectors and clamps at top of cable.
- b) Adjust steel support cable to proper length and tighten screws.

- c) Loosen upper cable grip and pull excess cable into connection box at hoist.
- d) Tighten cable grip and cut off excess cable.
- e) Strip cable sheath and connect wires with the same type of terminals previously furnished (care must be taken to match previous wire color coding with wire markers in accordance with the wiring diagram furnished with the hoist).

SECTION VIII - WIRING DIAGRAMS

8-1. GENERAL

Comprehensive wiring diagrams for YALE electric hoists have been omitted from this book because of the many possible variations. This is due to different currents and types of electrical components used in their construction. Figures 8-1 and 8-2 are examples of typical two-speed hoist and trolley wiring diagrams respectively. However, please consult the exact wiring diagrams for your hoist. A print of the correct wiring diagram for each hoist is furnished as a separate insert and shipped with the hoist. We suggest you carefully file the wiring diagram with this book for future reference.

NOTES



ELEMENTARY DIAGRAM




















FIGURE 8-2. COMPONENT DIAGRAM FOR A TWO-SPEED HOIST AND TROLLEY WITH STANDARD FEATURES

WIRE #	DEVICE CONNECTED
L1	HFU, CFU, PPD
L2	HFU, CFU, PPD
L3	HFU, CFU, PPD
HL1	HFU, U-D, PFU
HL2	HFU, U-D, PFU
HL3	HFU, U-D
CL1	CFU, R-L
CL2	CFU, R-L
CL3	CFU, R-L
PL1	PFU, HCPT
PL2	PFU, HCPT
A	U-D, F
C	U-D, F
D	R-L, FC
F	R-L, FC
HO1	F, HSOL
HO2	U-D, HSOL, HFOL
HO3	F, HSOL
HO11	F, HFOL
HO13	F, HFOL
CO1	FC, CSOL
CO2	R-L, CSOL, CFOL
CO3	FC, CSOL
CO11	FC, CFOL
CO13	FC, CFOL
HT1	HSOL
HT2	HSOL
HT3	HSOL
HT11	HFOL
HT12	HFOL
HT13	HFOL
CT1	CSOL
CT2	CSOL
CT3	CSOL
CT11	CFOL
CT12	CFOL
CT13	CFOL
0	TB OLC
0A	TB D, U, MC
0B	TB MC
0C	TB HSOL
0D	HSOL, HFOL
0E	HFOL, OLC, MC
0H	OLC, D, BCM
1	TB
1A	TB U, D, MC
1H	TB U, BCM
2	TB TDR
2A	TB TDR, F, MC
19	TB OLC
40	TB
40A	TB L, R
40B	TB CSOL
40C	TB CSOL, CFOL
40D	TB CFOL, L
41	TB
41A	TB R, L
42	TB FC
H91	TB PPD, BCM, MC
H91A	TB HCFU, PPD
92	TB HCPT, OLC, U, D, F, BCM, MC, R, L, FC
CB1	TB R-L
CB2	TB R-L
HB1	TB BCM
HB2	TB BCM



CONNECT PER
NAMEPLATE FOR
PROPER VOLTAGE



DANGER:

(PPD) - PHASE REVERSAL/LOSS PROTECTION DEVICE SHOWS A STEADY AMBER LED WHEN IN PHASE REVERSAL CONDITION.
CORRECT IMPROPER PHASING BY INTER-CHANGING INPUT POWER LEADS L1 AND L2.
DO NOT CHANGE PUSHBUTTON OR MOTOR CIRCUIT WIRING.

WARNING:

THIS EQUIPMENT MUST BE EFFECTIVELY GROUNDED ACCORDING TO APPLICABLE CODES.

AVERTISSEMENT:

CET EQUIPEMENT DOIT ETRE MIS A LA TERRE EN ACCORDANCE AVEC LES NORMES EN VIGUEUR.

PPD - PHASE REV./LOSS PROTECTION DEVICE
HFU - HOIST MOTOR CIRCUIT FUSING
PFU - TRANSFORMER PRIMARY FUSING
HCPT - CONTROL CIRCUIT TRANSFORMER
HCFU - CONTROL CIRCUIT FUSING
U - HOIST UP CONTACTOR
D - HOIST DOWN CONTACTOR
F - HOIST FAST SPEED CONTACTOR
HSOL - HOIST SLOW SPEED THERMAL OVERLOAD RELAY
HFOL - HOIST FAST SPEED THERMAL OVERLOAD RELAY
LSU - HOIST UPPER GEAR TYPE LIMIT SWITCH
LSD - HOIST LOWER GEAR TYPE LIMIT SWITCH
BCM - D.C. BRAKE CONTROL MODULE
TDR - TIMER DELAY MODULE
HTAS - HOIST MOTOR TEMPERATURE ACTUATED SWITCH
OLS - OVERLOAD LIMIT SWITCH
OLC - OVERLOAD LIMIT SWITCH CONTACTOR

SYMBOL DESIGNATIONS

CFU - TROLLEY MOTOR CIRCUIT FUSING
R - TROLLEY RIGHT CONTACTOR
L - TROLLEY LEFT CONTACTOR
FC - TROLLEY FAST CONTACTOR
CSOL - TROLLEY SLOW SPEED THERMAL OVERLOAD RELAY
CFOL - TROLLEY FAST SPEED THERMAL OVERLOAD RELAY
CTAS - TROLLEY MOTOR TEMPERATURE ACTIVATED SWITCH
MC - MONITOR CARD
TB - TERMINAL BOARD
G - FRAME GROUND
F -

SECTION IX - PARTS LIST

9-1. GENERAL

The parts lists and illustrations in this section of the manual cover parts for models of YALE "Global King" Electric hoists. A typical hoist is shown as the basis for the exploded parts illustrations; therefore, certain variations may occur from the information given. For this reason, always give the Hoist Serial Number, Catalog Number, Motor Horsepower, Voltage, Phase, Frequency and Capacity of Hoist when ordering parts.

Throughout this manual, you will see references to the "S2" and "S4" Frame hoists. If you are unsure about which frame you have, count the number of rope falls that are supporting the lower block and/or see Section IV, Paragraph 4-2 for a simple gearcase measurement to determine the configuration of your hoist. Your gearcase should have a similar shape to that shown and will measure 10 in width and requires approximately 3 quarts of oil.

Certain parts of your hoist will, in time, require replacement under normal wear conditions. It is suggested that these parts be purchased for your hoist as spares for future use. These parts are listed at the end of this manual.

The numbers assigned to parts of our various assemblies in our Parts List are the part numbers used in manufacturing. Some of these itemized parts are not for individual sale, but must be grouped with other related replacement items.

WHEN ORDERING PARTS OR INFORMATION ON THIS EQUIPMENT, ALWAYS INCLUDE MODEL AND SERIAL NUMBER ON ORDER.

WARNING

Using "Commercial" or other manufacturer's parts to repair Global King Hoists may cause load loss.



TO AVOID INJURY:

Use only YALE Hoist supplied parts. Parts may look alike but YALE Hoist parts are made of specific materials or processed to achieve specific properties.

**PARTS
STAR** 
BY COLUMBUS MCKINNON

LIST OF PART ILLUSTRATIONS

TITLE	FIGURE No.	PAGE No.
"A" Frame S4 Reeved & "A" Frame S2 Reeved	-	30-31
Hoist Drum, Drum Frame, Gearcase, Motor, Rope Guide, and Limit Switch	9-1	32-34
Hoist Gearing	9-2	35-36
Motor Driven Trolley Frame and Drive	9-3	37-38
Lower Block Assembly	9-4	39-40
Upper Block Assembly	9-5	41
Wire Rope Dead End Assembly with Limit Switch	9-6	42-43
Rope Guide Assembly	9-7	44
Block Operated Limit Switch "A"	9-8	45
Hoist Motor Brake – Standard Service (ABM Motor)	9-9	46-47
Hoist Motor Brake – Outdoor Service (ABM Motor)	9-10	48-49
Hoist Motor Brake – Standard Service (MGM Motor)	9-11	50
Hoist Motor Brake – Outdoor Service (MGM Motor)	9-12	50





ITEM #	PART #	DESCRIPTION	QTY.
1	SEE TABLE	BAR ALIGNMENT 2 1/4 X 34 3/16	2
2	SEE TABLE	THREADED ROD, M12 X 24"	2
3	44945003	MOTOR/GEAR CASE ASSEMBLY	1
4	SEE TABLE	ROPE DRUM-6.4 mm ROPE	1
5	SEE TABLE	CROSS SHAFT 1 DIA. X.32 LONG	1
6	23384001	PINION TRAVERSE	2
7	32879626	MOTOR 0.5/0.187 HP, 1800 RPM, 460v-3-B0	1
8	11784001	CAPLUG 1/4"	2
9	905378	SINGLE WORM GEAR REDUCER	1
10	23383901	TORQUE ARM BRACKET	1
11	SEE TABLE	DRUM FRAME ROD - 3/4 DIA. X "A" LONG	2
12	44949601	LOWER BLOCK ASSEMBLY	1
13	SEE TABLE	DRUM SIDE ASM.	1
14	SEE TABLE	TRANSVERSE SIDE ASM.	1
15	33296601	OUTBOARD ASSEMBLY	1
16	SEE TABLE	COUNTER WEIGHT	1
17	45042501	CONTROL ENCLOSURE - 24 x 16 x 6.8	1
18	10378807	BALL BEARING WITH SNAP RING (6205-16-2RSNR)	2
19	118025-20	HIGH STRENGTH BOLT, HEX HEAD 12mm-1.75 x 60mm Lg. CLASS 8.8	6
20	11803003	12mm-1.75 ESNA SELF LOCKING NUT (PLATED)	6
21	31493324	KEEPER PLATE	3
22	11803203	M10, HI-COLLAR LOCKWASHER	10
23	118027-07	10mm-1.50 HEX SHCS	10
24	11803402	M16 LOCKWASHER	2
25	118026-04	HIGH STRENGTH BOLT, HEX HEAD 16mm-2.00 x 40mm Lg. CLASS 8.8	2
26	11809401	M12 LOCKWASHER	4
27	11680704	SIZE 40 BUMPER, M8 STUD WITH NUT AND LOCKWASHER	4
28	NO-8526	5/16 LOCKWASHER, MEDIUM SERIES (PLATED)	4
29	10392029	5/16-18 X 0.875 SHCS PLAIN SELF-LOCKING	4
30	NO-1951	3/8 LOCKWASHER, MEDIUM SERIES (PLATED)	4
31	10791731	HEX BOLT GRADE 5, 3/8-16 x 1 (PLATED)	5
32	10387202	HEX TAP BOLT, 3/8-16 x 2 (PLATED)	4
33	NO-1948	3/8-16 SEMIFINISHED HEX NUT (PLATED)	8
34	10327304	3/8 ESNA SELF LOCKING NUT	5
35	43981305	LIMIT SWITCH GEARED NEMA 4/12	1
36	44943801	ROPE GUIDE "A" FRAME	1
37	11802906	M12-1.75 HEX NUT, CLASS 8	12
38	10231001	WASHER FLAT 1	2
39	11849801	M6-1.00 x 10mm CUP POINT SET SCREW	6
40	11781101	1/4 x 1/4 x 3/4 LG KEY	2
41	10846002	EXTERNAL RETAINING RING (TRUARC 5160-118)	1
42	23397701	ROPE CLAMP	3
43	118027-21	M6-1.00 HEX SHCS	3
44	11803205	M6, HI-COLLAR LOCKWASHER	3
45	SEE TABLE	ROPE ASSEMBLY	1

DETAIL C
SCALE 1"=2'
2 PLACES

"A" Frame S4 Reeved

ITEM 1	ITEM 5	ITEM 4	ITEM 11	ITEM 13	ITEM 14	ITEM 2	ITEM 16	ITEM 45	BEAM FLANGE WIDTH	LIFT (FT)
BAR ALIGNMENT	TRANSVERSE CROSS SHAFT	ROPE DRUM	DRUM FRAME ROD	DRUM SIDE ASM.	TRANSVERSE SIDE ASM.	TREADED ROD M12	COUNTER WEIGHT	ROPE ASSEMBLY		
23384204	23382908	44943901	23385903	45414204	45414304	10424761	45406501	23397901	3.25	20
23384207	23382911								4.63 - 6	
23384201	23382901			45414201	45414301	10424768			6.13 - 10	
23384202	23382902					10424769			10.13 - 14	
23384204	23382908	44943902	23385904	45414205	45414305	10424761	45406502	23397902	3.25	40
23384207	23382911								4.63 - 6	
23384201	23382901			45414202	45414302	10424768			6.13 - 10	
23384202	23382902					10424769			10.13 - 14	
23384204	23382908	44943903	23385905	44933206	44933216	10424761	45406503	23397904	3.25	60
23384207	23382911								4.63 - 6	
23384201	23382901			45414203	45414303	10424768			6.13 - 10	
23384202	23382902					10424769			10.13 - 14	



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	SEE TABLE	BAR ALIGNMENT 2 1/4 X 3/4 3/16	2
2	SEE TABLE	THREADED ROD, M12 X 24"	2
3	44945023	GEARCASE/MOTOR/DRUM BRACKET SUB-ASSEMBLY	1
4	SEE TABLE	ROPE DRUM-5.4 mm ROPE	1
5	SEE TABLE	CROSS SHAFT 1 DIA. X 32 LONG	1
6	23384031	PINION TRAVERSE	2
7	32679616	MOTOR 0.25/0.08 HP, 1800/600 RPM, 460v-3-Ø	1
8	11784001	CAP LUG 1/4"	2
9	905378	SINGLE WORM GEAR REDUCER	1
10	23383931	TORQUE ARM BRACKET	1
11	SEE TABLE	DRUM FRAME ROD - 3/4 DIA. X "A" LONG	2
12	44944101	LOWER BLOCK ASSEMBLY	1
13	SEE TABLE	DRUM SIDE ASM.	1
14	SEE TABLE	TRANSVERSE SIDE ASM.	1
15	33296631	OUTBOARD ASSEMBLY	1
16	SEE TABLE	COUNTER WEIGHT	1
17	45042501	CONTROL ENCLOSURE - 24 x 16 x 5.8	1
18	10378807	BALL BEARING WITH SNAP RING (6205-16-2RSNR)	2
19	118025-20	HIGH STRENGTH BOLT, HEX HEAD 12mm-1.75 x 60mm Lg. CLASS 8.8	8
20	11803003	12mm-1.75 ESNA SELF-LOCKING NUT (PLATED)	8
21	31493324	KEEPER PLATE	3
22	11803208	M10, HI-COLLAR LOCKWASHER	10
23	118027-07	10mm-1.50 HEX SHCS	10
24	11803402	M16 LOCKWASHER	2
25	118026-04	HIGH STRENGTH BOLT, HEX HEAD 16mm-2.00 x 40mm Lg. CLASS 8.8	2
26	11803401	M12 LOCKWASHER	4
27	11880704	SIZE 40 BUMPER, M8 STUD WITH NUT AND LOCKWASHER	4
28	NO-8526	5/16 LOCKWASHER, MEDIUM SERIES (PLATED)	4
29	10392029	5/16-18 X 0.875 SHCS PLAIN SELF-LOCKING	4
30	NO-1951	3/8 LOCKWASHER, MEDIUM SERIES (PLATED)	4
31	10791731	HEX BOLT GRADE 5, 3/8-16 x 1 (PLATED)	5
32	10387202	HEX TAP BOLT, 3/8-16 x 2 (PLATED)	4
33	NO-1948	3/8-16 SEMIFINISHED HEX NUT (PLATED)	8
34	10327334	3/8 ESNA SELF-LOCKING NUT	5
35	43981305	LIMIT SWITCH GEARED NEMA 4/12	1
36	44940801	ROPE GUIDE "A" FRAME	1
37	11802936	M12-1.75 HEX NUT, CLASS 8	12
38	10231031	WASHER FLAT 1	2
39	11802301	M6-1.00 x 10mm CUP POINT SET SCREW	6
40	11781101	1/4 x 1/4 x 3/4 LG KEY	2
41	10848002	EXTERNAL RETAINING RING (TRUARC 5160-118)	1
42	23397701	ROPE CLAMP	3
43	11803205	M8, HI-COLLAR LOCKWASHER	3
44	118027-21	M6-1.00 HEX SHCS	3
45	SEE TABLE	ROPE ASSEMBLY	1

"A" Frame S2 Reeved

ITEM 1	ITEM 5	ITEM 4	ITEM 11	ITEM 13	ITEM 14	ITEM 2	ITEM 16	ITEM 45	BEAM FLANGE WIDTH	LIFT (FT)
BAR ALIGNMENT	TRANSVERSE CROSS SHAFT	ROPE DRUM	DRUM FRAME ROD	DRUM SIDE ASM.	TRANSVERSE SIDE ASM.	TREADED ROD M12	COUNTER WEIGHT	ROPE ASSEMBLY		
23384204	23382908	44943901	23385903	45415602	45415902	10424761	45406501	23397903	3.25	40
23384207	23382911			45415601	45414901	10424768		4.63 - 6		
23384201	23382901							6.13 - 10		
23384202	23382902							10.13 - 14		




Figure 9-1. Hoist Drum, Drum Frame, Gearcase, Motor, Rope Guide and Screw Type Limit Switch

“A” Frame: Hoist Components for Figure 9-1.

REF. No.	Part Number	Description	Qty. Req'd
1	43981305	LIMIT SWITCH GEARED NEMA 4/12	1
2	11593901	DRUM SHAFT INSERT	1
3	11802612	HIGH STRENGTH BOLT, HEX HEAD 10mm-1.50 x 35mm Lg. CLASS 8.8	2
4	11803404	M10 LOCKWASHER 4	
5	10846002	RETAINING RING EXTERNAL	1
6	23395801	MOUNTING BRACKET	1
7	11802707	10mm-1.50 HEX SHCS	8
8	11803203	M10, HI-COLLAR LOCKWASHER	8
9	11801805	FLANGED CARTRIDGE BEARING FHFC206-30-NLC	1
10	33296332	DRUM FRAME BRACKET (LH)	1
11	23397701	ROPE CLAMP	3
12	11802721	M6-1.00 HEX SHCS	3
13	11803205	M6, HI-COLLAR LOCKWASHER	3
14	11803003	12mm-1.75 ESNA SELF LOCKING NUT (PLATED)	6
15	45402901	DRUM SIDE ASM. (MACHINED)	1
16	11680704	SIZE 40 BUMPER, M8 STUD WITH NUT AND LOCKWASHER	2
17	31493324	KEEPER PLATE	2
18	11803101	M10 FLAT WASHER	4
19	11802723	10mm-1.50 HEX SHCS	2
20	11802606	HIGH STRENGTH BOLT, HEX HEAD 10mm-1.50 x 40mm Lg. CLASS 8.8	2
21	44943501C 44943502C	GEARCASE ASSEMBLY (3.2 tonne) GEARCASE ASSEMBLY (1.6 tonne)	1

(continued on next page)

“A” Frame: Hoist Components for Figure 9-1.

REF. No.	Part Number	Description	Qty. Req'd
22	See charts below	HOIST MOTOR (TWO SPEED) (1.6 TONNE) HOIST MOTOR (TWO SPEED) (3.2 TONNE)	1
23	23385903 23385904	DRUM FRAME ROD - S2 MODEL & 20 FT. LIFT, S4 MODEL DRUM FRAME ROD - 40 FT. LIFT, S4 MODEL	2
24	11802520	HIGH STRENGTH BOLT	6
25	44943901 44943902	DRUM FRAME ROD - S2 MODEL & 20 FT. LIFT, S4 MODEL DRUM FRAME ROD - 40 FT. LIFT, S4 MODEL	1
26	44943801	ROPE GUIDE “A” FRAME	1
27	---	LOCK NUT, M10	8
28	11802613	HIGH STRENGTH BOLT	2
29	33296331	DRUM FRAME BRACKET	1
30a	44944701	SHAW-BOX Brand Label for Gearcase (Not Shown)	1
30b	44944702	YALE Brand Label for Gearcase (Not Shown)	1

2-SPEED ABM HOIST MOTORS

MOTOR 5.0/1.25 HP 3600/900 RPM	3.2 TONNE (S4 REEVING)	MOTOR 3.0/.75 HP 3600/900 RPM	1.6 TONNE (S2 REEVING)
POWER SUPPLY	PART NUMBER	POWER SUPPLY	PART NUMBER
208V-3PH-60HZ	33295001	208V-3PH-60HZ	33295501
230V-3PH-60HZ	33295002	230V-3PH-60HZ	33295502
460V-3PH-60HZ	33295003	460V-3PH-60HZ	33295503
575V-3PH-60HZ	33295004	575V-3PH-60HZ	33295504
380V-3PH-50HZ	33295005	380V-3PH-50HZ	33295505

2-SPEED ABM HOIST MOTORS WITH IP55 MOTOR BRAKE (OUTDOOR SERVICE)

MOTOR 5.0/1.25 HP 3600/900 RPM	3.2 TONNE (S4 REEVING)	MOTOR 3.0/.75 HP 3600/900 RPM	1.6 TONNE (S2 REEVING)
POWER SUPPLY	PART NUMBER	POWER SUPPLY	PART NUMBER
208V-3PH-60HZ	33297001	208V-3PH-60HZ	33297101
230V-3PH-60HZ	33297002	230V-3PH-60HZ	33297102
460V-3PH-60HZ	33297003	460V-3PH-60HZ	33297103
575V-3PH-60HZ	33297004	575V-3PH-60HZ	33297104
380V-3PH-50HZ	33297005	380V-3PH-50HZ	33297105

2-SPEED MGM HOIST MOTORS

MOTOR 5.0/1.25 HP 3600/900 RPM	3.2 TONNE (S4 REEVING)	MOTOR 3.0/.75 HP 3600/900 RPM	1.6 TONNE (S2 REEVING)
POWER SUPPLY	PART NUMBER	POWER SUPPLY	PART NUMBER
208V-3PH-60HZ	33330601	208V-3PH-60HZ	N/A
230V-3PH-60HZ	33330602	230V-3PH-60HZ	N/A
460V-3PH-60HZ	33330603	460V-3PH-60HZ	N/A
575V-3PH-60HZ	33330604	575V-3PH-60HZ	N/A
380V-3PH-50HZ	CALL FACTORY	380V-3PH-50HZ	N/A

INVERTER DUTY MGM HOIST MOTORS			
MOTOR 3.5 HP 1800 RPM	3.2 TONNE (S4 REEVING)	MOTOR 3.5 HP 1800 RPM	1.6 TONNE (S2 REEVING)
POWER SUPPLY	PART NUMBER	POWER SUPPLY	PART NUMBER
208V-3PH-60HZ	33336600	208V-3PH-60HZ	33336600
230V-3PH-60HZ		230V-3PH-60HZ	
460V-3PH-60HZ		460V-3PH-60HZ	
575V-3PH-60HZ	CONTACT FACTORY	575V-3PH-60HZ	CONTACT FACTORY

INVERTER DUTY MGM HOIST MOTORS WITH IP55 MOTOR BRAKE (OUTDOOR SERVICE)			
MOTOR 3.5 HP 1800 RPM	3.2 TONNE (S4 REEVING)	MOTOR 3.5 HP 1800 RPM	1.6 TONNE (S2 REEVING)
POWER SUPPLY	PART NUMBER	POWER SUPPLY	PART NUMBER
208V-3PH-60HZ	33336610	208V-3PH-60HZ	33336610
230V-3PH-60HZ		230V-3PH-60HZ	
460V-3PH-60HZ		460V-3PH-60HZ	
575V-3PH-60HZ	CONTACT FACTORY	575V-3PH-60HZ	CONTACT FACTORY

HOIST DYNAMIC BRAKING RESISTORS			
MOTOR 3.5 HP 1800 RPM	3.2 TONNE (S4 REEVING)	MOTOR 3.5 HP 1800 RPM	1.6 TONNE (S2 REEVING)
POWER SUPPLY	PART NUMBER	POWER SUPPLY	PART NUMBER
208V-3PH-60HZ	45430470	208V-3PH-60HZ	45430470
230V-3PH-60HZ		230V-3PH-60HZ	
460V-3PH-60HZ	45430474	460V-3PH-60HZ	45430474
575V-3PH-60HZ		575V-3PH-60HZ	






Figure 9-2. Hoist Gearing

“A” Frame S4 Reeved: Hoist Gearing for Figure 9-2.

REF. No.	Part Number	Description	Qty. Req'd
	44943501C	Complete 3200kg Hoist Gearcase Ass'y. - 75.14:1 Ratio	1
	44943590	Gearcase Gasket/Seal Kit (Incl. Ref. Nos. 3, 24, 25)	
	44943591	Gearcase Gasket/Bearings Kit (Incl. Ref. Nos. 3, 10, 15, 16, 20, 21, 23, 24, 25)	
1	N/A	Gearcase	1
2	N/A	Cover	1
3	N/A	Gasket	1
4	-	Vent Plug	1
5	-	Drain/Fill Level Plug	2
6	N/A	Socket Head Shoulder Screw, M6	2
7	N/A	Hi-Collar Lockwasher, M8	2
8	N/A	Socket Head Cap Screw, M6	7
9	N/A	Hi-Collar Lockwasher, M6	7
10	N/A	Ball Bearing	1
11	N/A	External Retaining Ring	1
12	N/A	Intermediate Gear	1
13	N/A	Drum Pinion Shaft	1
14	N/A	Key	1
15	N/A	Ball Bearing	1
16	N/A	Ball Bearing	1
17	N/A	Intermediate Pinion Shaft	1
18	N/A	Key	1
19	N/A	Motor Gear	1
20	N/A	Ball Bearing	1
21	N/A	Ball Bearing	1
22	N/A	Output Shaft	1
23	N/A	Roller Bearing	1
24	N/A	Output Shaft Oil Seal	1
25	N/A	Motor Shaft Oil Seal	1
26	N/A	Torque Pin	2
27	N/A	Threaded Stud, M10	4




Figure 9-2. Hoist Gearing

“A” Frame S2 Reeved: Hoist Gearing for Figure 9-2.

REF. No.	Part Number	Description	Qty. Req'd
	44943502C	Complete 1600kg Hoist Gearcase Ass'y. - 126.3:1 Ratio	1
	44943590	Gearcase Gasket/Seal Kit (Incl. Ref. Nos. 3, 24, 25)	
	44943591	Gearcase Gasket/Bearings Kit (Incl. Ref. Nos. 3, 10, 15, 16, 20, 21, 23, 24, 25)	
1	N/A	Gearcase	1
2	N/A	Cover	1
3	N/A	Gasket	1
4	-	Vent Plug	1
5	-	Drain/Fill Level Plug	2
6	N/A	Socket Head Shoulder Screw, M6	2
7	N/A	Hi-Collar Lockwasher, M8	2
8	N/A	Socket Head Cap Screw, M6	7
9	N/A	Hi-Collar Lockwasher, M6	7
10	N/A	Ball Bearing	1
11	N/A	External Retaining Ring	1
12	N/A	Intermediate Gear	1
13	N/A	Drum Pinion Shaft	1
14	N/A	Key	1
15	N/A	Ball Bearing	1
16	N/A	Ball Bearing	1
17	N/A	Intermediate Pinion Shaft	1
18	N/A	Key	1
19	N/A	Motor Gear	1
20	N/A	Ball Bearing	1
21	N/A	Ball Bearing	1
22	N/A	Output Shaft	1
23	N/A	Roller Bearing	1
24	N/A	Output Shaft Oil Seal	1
25	N/A	Motor Shaft Oil Seal	1
26	N/A	Torque Pin	2
27	N/A	Threaded Stud, M10	4




Figure 9-3. Motor Driven Trolley Frame and Drive

“A” Frame: Trolley Frame and Drive Components for Figure 9-3.

REF. No.	Part Number	Description	Qty. Req'd
1	45042501	CONTROL ENCLOSURE - 24 x 16 x 6.8	1
2	10327304	3/8 ESNA SELF LOCKING NUT	5
3	NO1948	3/8-16 SEMIFINISHED HEX NUT (PLATED)	8
4	11802604	HIGH STRENGTH BOLT, HEX HEAD 16mm-2.00 x 40mm Lg. CLASS 8.8	2
5	11803402	M16 LOCKWASHER	2
6	45406501	COUNTER WEIGHT	1
7	10387202	HEX TAP BOLT, 3/8-16 x 2 (PLATED)	4
8	11802906	M12-1.75 HEX NUT, CLASS 8	12
9	11803401	M12 LOCKWASHER	4
10	23384202	BAR ALIGNMENT 2 1/4 X 34 3/16	2
11	10119401	EXTERNAL RETAINING RING (TRUARC 5100-118)	4
12	NO8135	BEARING - SINGLE ROW RADIAL (TWO SHIELDS)	8
13	10008311	TRUARC SIZE 244 INTERNAL SNAP RING	4
14	33295922	PLAIN WHEEL ASSM PAIR* (INCL. REF NOS. 11, 12, 13, 15 & 16)	2
15	23400301	WHEEL AXLE	4
16	10119409	EXTERNAL RETAINING RING (TRUARC 5100-100)	4
17	45402901	DRUM SIDE ASM. (MACHINED)	1
18	11680704	SIZE 40 BUMPER, M8 STUD WITH NUT AND LOCKWASHER	2

*Note: Also used on 3.25" patented track

(continued on next page)

“A” Frame: Trolley Frame and Drive Components for Figure 9-3.

REF. No.	Part Number	Description	Qty. Req'd
19	10378807	BALL BEARING WITH SNAP RING (6205-16-2RSNR)	2
20	10231001	WASHER FLAT	2
21	23384001	PINION TRAVERSE	2
22	11781101	1/4 x 1/4 x 3/4 LG KEY	2
23	11849801	M6-1.00 x 10mm CUP POINT SET SCREW	6
24	23382902	TRAVERSE CROSS SHAFT	1
25	10424769	THREADED ROD, M12 X 24"	2
26	33295921	GEARED WHEEL ASSM PAIR* (INCL. REF NOS. 11, 12, 13, 15 & 16)	2
27	45403101	TRANSVERSE SIDE ASM.	1
28	31493324	KEEPER PLATE	1
29	See chart below	MOTOR 0.5/0.167 HP, 1800 RPM, 460v-3-60	1
30	11803203	M10, HI-COLLAR LOCKWASHER	2
31	11802707	10mm-1.50 HEX SHCS	2
32	10392029	5/16-18 X 0.875 SHCS PLAIN SELF-LOCKING	4
33	NO8526	5/16 LOCKWASHER, MEDIUM SERIES (PLATED)	4
34	23383901	TORQUE ARM BRACKET	1
35	10791731	HEX BOLT GRADE 5, 3/8-16 x 1 (PLATED)	4
36	NO1951	3/8 LOCKWASHER, MEDIUM SERIES (PLATED)	4
37	905378	SINGLE WORM GEAR REDUCER	1

*Note: Also used on 3.25" patented track


2-SPEED TROLLEY MOTORS			
MOTOR .5/.17 HP 1800/600 RPM	3.2 TONNE (S4 REEVING)	MOTOR .25/.08 HP 1800/600 RPM	*1.6 TONNE (S2 REEVING)
POWER SUPPLY	PART NUMBER	POWER SUPPLY	PART NUMBER
208V-3PH-60HZ	32879624	208V-3PH-60HZ	32879615
230V-3PH-60HZ	32879625	230V-3PH-60HZ	32879615
460V-3PH-60HZ	32879626	460V-3PH-60HZ	32879616
575V-3PH-60HZ	32879627	575V-3PH-60HZ	32879617
380V-3PH-50HZ	11704229	380V-3PH-50HZ	11704128

*Note: 1.6 tonne models with bolted frame use .25/.08 HP motors.
1.6 tonne models with new welded frame use .5/.17 HP motors.
Please verify HP rating of trolley motor prior to order.

1-SPEED TROLLEY MOTORS †			
MOTOR .5/.17 HP 1800/600 RPM	3.2 TONNE (S4 REEVING)	MOTOR .25/.08 HP 1800/600 RPM	*1.6 TONNE (S2 REEVING)
POWER SUPPLY	PART NUMBER	POWER SUPPLY	PART NUMBER
208V-3PH-60HZ	32879532	208V-3PH-60HZ	32879522
230V-3PH-60HZ	32879532	230V-3PH-60HZ	32879522
460V-3PH-60HZ	32879532	460V-3PH-60HZ	32879522
575V-3PH-60HZ	32879533	575V-3PH-60HZ	32879523

† Also furnished with trolley VFC

Figure 9-4a. Lower Block Assembly



“A” Frame S4 Reeved: Lower Block Components for Figure 9-4a.

REF. No.	Part Number	Description	Qty. Req'd
	44943601C	Lower Block Assembly (Excludes Ref. Nos. 17 & 18)	1
	33296201	Sheave Assembly (Incl. Ref. Nos. 12, 13, 14)	
	4X1307	Hook Latch Kit (Not shown)	
	23398091	Hook Assembly (Incl. Ref. Nos. 2, 3, 4)	
1	N/A	Trunnion Crosshead	1
2	N/A	Hook & Nut Assembly	1
3	N/A	Thrust Bearing	1
4	N/A	Roll Pin	1
5	N/A	Sheave Pin	1
6	N/A	Spacer Tube	2
7	N/A	Lower Block Strap	2
8	33296501	Inner Sheave Cover	2
9	N/A	Flat Washer, M8	4
10	N/A	Socket Head Cap Screw, M8	2
11	N/A	Locknut, M8	2
12	N/A	Rope Sheave	2
13	N/A	Ball Bearing	4
14	N/A	Internal Retaining Ring	2
15	N/A	External Retaining Ring	2
16	33296511	Outer Sheave Cover	2
17	23382880	3200 kg Capacity Label	2
18a	23382801	SHAW-BOX Brand Label	2
18b	23382802	YALE Brand Label	2
19	N/A	Socket Head Cap Screw, M6	6
20	N/A	Locknut, M6	6




Figure 9-4b. Lower Block Assembly (S2 Reeved)

"A" Frame S2 Reeved: Lower Block Components for Figure 9-4b.			
REF. No.	Part Number	Description	Qty. Req'd
	44944101C	Lower Block Assembly (Excludes Ref. Nos. 14 & 15)	1
	33296201	Sheave Assembly (Incl. Ref. Nos. 7, 8, 9)	
	4X1304	Hook Latch Kit (Not Shown)	
	23398691	Hook Assembly (Incl. Ref. Nos. 2, 3, 4)	
1	N/A	Crosshead Weldment	1
2	N/A	Hook & Nut Assembly	1
3	N/A	Thrust Bearing	1
4	N/A	Roll Pin	1
5	N/A	Sheave Pin	1
6	N/A	External Retaining Ring	2
7	N/A	Rope Sheave	1
8	N/A	Internal Retaining Ring	1
9	N/A	Ball Bearing	2
10	N/A	Spacer Washer	2
11	33296701	Outer Sheave Cover	2
12	N/A	Socket Head Cap Screw, M8	4
13	N/A	Flat Washer, M8	4
14a	23382801	SHAW-BOX Brand Label	2
14b	23382802	YALE Brand Label	2
15	23382881	1600 kg Capacity Label	2
16	N/A	Socket Head Cap Screw, M6	3
17	N/A	Locknut, M6	3






Figure 9-5. Upper Block Assembly (S4 Reeved)

“A” Frame S4 Reeved: Upper Block Components for Figure 9-5.

REF. No.	Part Number	Description	Qty. Req'd
	44944001	“A” Frame Hoist Upper Block Assembly	1
	33296201	Sheave Assembly (Incl. Ref. Nos. 10, 11, 12)	
1	N/A	Upper Block Yoke	1
2	N/A	Yoke Pin	1
4	N/A	External Retaining Ring	2
5	N/A	Locknut, M6	2
6	N/A	Hex Head Bolt, M6	2
7	N/A	Sheave Pin	1
8	N/A	External Retaining Ring	2
9	N/A	Spacer Washer	2
10	N/A	Internal Retaining Ring	1
11	N/A	Sealed Ball Bearing	2
12	N/A	Rope Sheave	1

Figure 9-6
"A" Frame S4 Reeved:
Dead End/Overload Limit Assembly


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	10119409	EXTERNAL RETAINING RING (TRUARC 5100-100)	2
2	10119445	EXTERNAL RETAINING RING (TRUARC 5100-81)	2
3	11781503	BELLEVILLE SPRING, HDS10 (PRESET)	4
4	11802501	M6 X 70mm HEX HEAD CAP SCREW	2
5	11802801	M10 X 45mm SHOULDER SOCKET HEAD CAP SCREW	1
6	11803001	M6-1.00 ESNA SELF LOCKING NUT (PLATED)	2
7	11850701	CLEVIS PIN	1
8	11850801	COTTER PIN	1
9	23385401	YOKE DEAD END	1
10	23385701	OVERLOAD SPRING BASE FOR DEAD END	1
11	23385801	DEAD END PIN	1
12	23398802	YOKE SLEEVE	1
13	23399403	PIN YOKE	1
14	23566801	OVERLOAD BEAM	1




[2] APPLY THREADLOCK

SPRING STACK WITH WASHERS
IN SERIES ARRANGEMENT

3




DETAIL A
 SPRING STACK (IN SERIES) DETAIL
 SCALE: (4 : 1)




NOTES:

- [1] TORQUE SPECIFICATION:
ITEM 10 AND 16 MUST BE TIGHTENED TO A MINIMUM TORQUE VALUE OF 29 ft lbf
- [2] ITEM 11 MUST BE INSTALLED TO A TORQUE VALUE OF 29 ft lbf
AND THREADLOCKED USING LOCTITE 262 (P/N 10575522)
OR PERMA-LOK HM118 (P/N 10575529) OR EQUIVALENT.
CARE MUST BE TAKEN TO ASSURE ITEM 11 IS FULLY
THREADED INTO ITEM 2.
3. SEE INDIVIDUAL PART DRAWINGS FOR SURFACE TREATMENT REQUIREMENTS.

Figure 9-6
"A" Frame S2 Reeved:
Dead End/Overload Limit Assembly



ITEM NO.	PART NUMBER	DESCRIPTION	45423301/ QTY.
1	23385401	YOKE DEAD END	1
2	23566801	OVERLOAD BEAM	1
3	23385701	OVERLOAD SPRING BASE FOR DEAD END	1
4	23385801	DEAD END PIN	1
5	23397601	YOKE PIN WITH GROOVES	1
6	10119445	EXTERNAL RETAINING RING (TRUARC 5100-81)	2
7	11781503	BELLEVILLE SPRING, HDS10 (PRESET)	4
8	11802501	M6 X 70mm HEX HEAD CAP SCREW	2
9	11802801	M10 X 45mm SHOULDER SOCKET HEAD CAP SCREW	1
10	10119407	EXTERNAL RETAINING RING (TRUARC 5100-137)	2
11	11802601	M5 X 16mm HEX HEAD CAP SCREW	1
12	11802901	M5 HEX NUT	1
13	11803001	M6-1.00 ESNA SELF LOCKING NUT (PLATED)	2
14	11850701	CLEVIS PIN	1
15	11850801	COTTER PIN	1
16	11804901	YOKE SPACER	2



NOTES:

1. TORQUE SPECIFICATION:
ITEM 10 AND 16 MUST BE TIGHTENED TO A MINIMUM TORQUE VALUE OF 105 in lbf
2. ITEM 11 MUST BE INSTALLED TO A TORQUE VALUE OF 29 ft lbf
AND THREADLOCKED USING LOCTITE 262 (P/N 10575522)
OR PERMA-LOK HM118 (P/N 10575529) OR EQUIVALENT.
CARE MUST BE TAKEN TO ASSURE ITEM 11 IS FULLY
THREADED INTO ITEM 2.
3. SEE INDIVIDUAL PART DRAWINGS FOR SURFACE TREATMENT REQUIREMENTS.




Figure 9-7. Rope Guide Assembly

"A" Frame: Rope Guide Components for Figure 9-7.			
REF. No.	Part Number	Description	Qty. Req'd
	44943801C	"A" Frame Rope Guide Assembly	1
1	N/A	Rope Guide Body	1
2	N/A	Plastic Shroud	1
3	N/A	Socket Head Shoulder Bolt, M6 Thread	2
4	N/A	Compression Spring	2
5	N/A	Extension Spring	1







Figure 9-8. Block Operated Limit Switch “A”

“A” Frame: Block Operated Limit Switch Components for Figure 9-8.			
REF. No.	Part Number	Description	Qty. Req’d
	33290505C	Block Operated Limit Switch	1
1	N/A	Limit Switch Bracket	1
2	N/A	Limit Switch	1
3	N/A	Limit Switch Hub	1
4	N/A	Actuator Rod	1
5	N/A	Pan Head Screw, #10	2
6	N/A	Lockwasher #10	2
7	N/A	Socket Head Cap Screw, #10	2






Figure 9-9. Standard Hoist Motor Brake

“A” S4 Frame: Hoist Brake Components for Figure 9-9. (ABM Motor)

REF. No.	Part Number	Description	Qty. Req'd
	33295049	Complete Brake Assembly (Includes Ref. Nos. 1,11,16,17 & P/N 33313853)	1
1	33313850	Brake Friction Disc	1
2		Fan	1
3	33295051	External Retaining Rings (Fan Hub)	-
4	BRAKE	External Retaining Ring (Fan)	1
5	FAN	Fan Hub	-
6	KIT	Key (Fan Hub)	-
7		Key (Fan)	1
8	33313852	External Retaining Ring (Brake Hub)	1
9	BRAKE	Spacer (Brake Hub)	1
10	HUB	Key (Brake Hub)	1
11	KIT	Brake Hub	1
12	33313853	Hollow Core Bolts	3
13	HARD-	O-Ring	1
14	WARE	Bolts (Brake Mounting)	3
15	KIT	Compression Springs	5*
16	N/A	Magnet Body - Order Complete Brake	1
17	N/A	Armature Plate - Order Complete Brake	1
18	33295055	Fan Shroud	1
19	SHROUD KIT	Bolts (Fan Shroud)	4

* Kit comes with (7) springs, but only (5) are utilized in this assembly.




Figure 9-9. Standard Hoist Motor Brake

“A” S2 Frame: Hoist Brake Components for Figure 9-9. (ABM Motor)

REF. No.	Part Number	Description	Qty. Req'd
	33295549	Complete Brake Assembly (Includes Ref. Nos. 1,11,16,17 & P/N 33295553)	1
1	33295550	Brake Friction Disc	1
2		Fan	1
3	33295551	External Retaining Rings (Fan Hub)	-
4	BRAKE	External Retaining Ring (Fan)	1
5	FAN	Fan Hub	-
6	KIT	Key (Fan Hub)	-
7		Key (Fan)	1
8	33295552	External Retaining Ring (Brake Hub)	1
9	BRAKE	Spacer (Brake Hub)	1
10	HUB	Key (Brake Hub)	1
11	KIT	Brake Hub	1
12	33295553	Hollow Core Bolts	3
13	HARD-	O-Ring	1
14	WARE	Bolts (Brake Mounting)	3
15	KIT	Compression Springs	7
16	N/A	Magnet Body - Order Complete Brake	1
17	N/A	Armature Plate - Order Complete Brake	1
18	33295555	Fan Shroud	1
19	SHROUD KIT	Bolts (Fan Shroud)	4




Figure 9-10. Outdoor Service Hoist Motor Brake

“A” S4 Frame: Hoist Brake Components for Figure 9-10. (ABM Motor)			
REF. No.	Part Number	Description	Qty. Req'd
	33297049	Complete Brake Assembly (Includes Ref. Nos. 1,11,16,17, 18 & P/N 33294053)	1
1	33313850	Brake Friction Disc	1
2		Fan	1
3	33295051	External Retaining Rings (Fan Hub)	-
4	BRAKE	External Retaining Ring (Fan)	1
5	FAN	Fan Hub	-
6	KIT	Key (Fan Hub)	-
7		Key (Fan)	1
8	33294052	External Retaining Ring (Brake Hub)	1
9	BRAKE	Spacer (Brake Hub)	1
10	HUB	Key (Brake Hub)	1
11	KIT	Stainless Steel Brake Hub	1
12	33294053	Hollow Core Bolts	3
13	HARD-	O-Ring	1
14	WARE	Bolts (Brake Mounting)	3
15	KIT	Compression Springs	5*
16	N/A	Magnet Body - Order Complete Brake	1
17	N/A	Stainless Steel Armature Plate - Order Complete Brake	1
18	N/A	Stainless Steel Friction Disc - Order Complete Brake	1
19	11803105	Spacer Washers	4
20	33295055	Fan Shroud	1
21	SHROUD KIT	Bolts (Fan Shroud)	4

* Kit comes with (7) springs, but only (5) are utilized in this assembly.





Figure 9-10. Outdoor Service Hoist Motor Brake

“A” S2 Frame: Hoist Brake Components for Figure 9-10. (ABM Motor)

REF. No.	Part Number	Description	Qty. Req'd
	33297149	Complete Brake Assembly (Includes Ref. Nos. 1,11,16,17, 18 & P/N 33297153)	1
1	33295550	Brake Friction Disc	1
2		Fan	1
3	33295551	External Retaining Rings (Fan Hub)	-
4	BRAKE	External Retaining Ring (Fan)	1
5	FAN	Fan Hub	-
6	KIT	Key (Fan Hub)	-
7		Key (Fan)	1
8	33297152	External Retaining Ring (Brake Hub)	1
9	BRAKE	Spacer (Brake Hub)	-
10	HUB	Key (Brake Hub)	1
11	KIT	Stainless Steel Brake Hub	1
12	33297153	Hollow Core Bolts	3
13	HARD-	O-Ring	1
14	WARE	Bolts (Brake Mounting)	3
15	KIT	Compression Springs	7
16	N/A	Magnet Body - Order Complete Brake	1
17	N/A	Stainless Steel Armature Plate - Order Complete Brake	1
18	N/A	Stainless Steel Friction Disc - Order Complete Brake	1
19	11803107	Spacer Washers	4
20	33295555	Fan Shroud	1
21	SHROUD KIT	Bolts (Fan Shroud)	4



ITEM NO.	DESCRIPTION
1	SPRINGS
2	BRAKE ADJUSTERS
3	LOCK NUTS
4	NUTS
5	NUTS
6	BRAKE DISC
7	MOVING ELEMENT
8	BRAKE COIL
9	END COVER
10	REAR NUT

Figure 9-11 & 9-12. Standard and Outdoor Service Hoist Motor Brakes

"A" S4 Frame: Standard Hoist Brake Components for Figure 9-11. (MGM Motor)			
REF. No.	Part Number	Description	Qty. Req'd
	33330649	Complete Brake Assembly (Includes Ref Nos. 1-10)	1
	33330650	Brake Adjuster Set (Includes Ref Nos. 1-5)	1
6	33330651	Brake Disc	1
7	33330652	Brake Moving Element	1
8	33330653	24V DC brake Coil	1
9	33330654	Brake Cover	1
10	33327355	Plastic Hexagonal Nut (Standard Brake)	1

"A" S4 Frame: Outdoor Service Hoist Brake Components for Figure 9-12. (MGM Motor)			
REF. No.	Part Number	Description	Qty. Req'd
	33330659	Complete Brake Assembly (Includes Ref Nos. 1-10)	1
	33330650	Brake Adjuster Set (Includes Ref Nos. 1-5)	1
6	33330651	Brake Disc	1
7	33330652	Brake Moving Element	1
8	33330653	24V DC brake Coil	1
9	33330654	Brake Cover	1
10	33327360	Hexagonal Nut with Seal (IP55 Brake)	1

RECOMMENDED SPARE PARTS

Certain parts of your hoist will, in time, require replacement under normal wear conditions. It is suggested that the following parts be purchased for your hoist as spares for future use.

- One Brake Friction Disc
- One Brake Control Module
- One Brake Hardware Kit
- One Set of Contactors
- One Transformer
- One Wire Rope Assembly

Note: When ordering parts always furnish Hoist Serial Number, Catalog Number, Motor Horsepower, Voltage, Phase, Frequency and Rated Load of Hoist on which the parts are to be used.

PARTS AND SERVICES ARE AVAILABLE IN THE UNITED STATES AND IN CANADA

Parts for your hoist or trolley are available from your local authorized repair station. For the name of the nearest parts or service center, visit our website www.cmworks.com or call the Columbus McKinnon customer service department at (800) 888-0985.



HOOSIER CRANE
SERVICE COMPANY

NOTES



HOOSIER CRANE
SERVICE COMPANY

WARRANTY

LIMITATION OF WARRANTIES, REMEDIES AND DAMAGES

INDEMNIFICATION AND SAFE OPERATION

Buyer shall comply with and require its employees to comply with directions set forth in instructions and manuals furnished by Seller and shall use and require its employees to follow such instructions and manuals and to use reasonable care in the use and maintenance of the goods and any replacement parts. Buyer shall not remove or permit anyone to remove any warning or instruction signs on the goods or replacement parts. In the event of personal injury or damage to property or business arising from the use of the goods or replacement parts, Buyer shall within 48 hours thereafter give Seller written notice of such injury or damage. Buyer shall cooperate with Seller in investigating any such injury or damage and in the defense of any claims arising therefrom.

If Buyer fails to comply with this section or if any injury or damage is caused, in whole or in part, by Buyer's failure to comply with applicable federal or state laws, rules or regulations safety requirements, Buyer shall indemnify and hold Seller harmless against any claims, loss or expense for injury or damage arising from the use of the goods and/or replacement parts.

CMCO Warranty (HOISTS)

A. Columbus McKinnon Corporation ("Seller") warrants to the original end user ("Buyer") that, for a period of one (1) year from the date of Seller's delivery of the goods (collectively, the "Goods") to the carrier, the Goods will be free from defects in workmanship and materials. (b) for a period of three (3) years from the date of Seller's delivery of the Goods to the carrier, the brake discs on the Goods will be free from defects in workmanship and materials; and (c) for the life of the Goods, the mechanical components including, without limitation, the sidewinder hoist lever, of the Goods (other than the brake discs on the Goods) will be free from defects in workmanship and materials. In addition, Seller warrants to Buyer that, for a period of one (1) year from the date of their delivery by Seller to the carrier, any aftermarket or replacement parts, accessories or components purchased by Buyer with respect to any Goods (collectively, "Replacement Parts") will be free from defects in workmanship and materials.

B. IN THE EVENT OF ANY BREACH OF ANY SUCH WARRANTY, SELLER'S SOLE OBLIGATION SHALL BE EXCLUSIVELY LIMITED TO, AT THE OPTION OF SELLER, REPAIR OR REPLACEMENT, F.O.B. SELLER'S POINT OF SHIPMENT, OF ANY GOODS OR REPLACEMENT PARTS THAT SELLER DETERMINES TO HAVE BEEN DEFECTIVE OR, IF SELLER DETERMINES THAT SUCH REPAIR OR REPLACEMENT IS NOT FEASIBLE, TO A REFUND OF THE PURCHASE PRICE UPON RETURN OF THE GOODS OR REPLACEMENT PARTS TO SELLER. NO CLAIM AGAINST SELLER FOR ANY BREACH OF (i) SUCH WARRANTY WITH RESPECT TO THE ELECTRICAL COMPONENTS OF ANY GOOD OR REPLACEMENT PARTS SHALL BE VALID OR ENFORCEABLE UNLESS BUYER'S WRITTEN NOTICE THEREOF IS RECEIVED BY SELLER WITHIN ONE (1) YEAR FROM THE DATE OF SELLER'S DELIVERY TO THE CARRIER, (ii) SUCH WARRANTY WITH RESPECT TO THE BRAKE DISCS OF ANY GOOD SHALL BE VALID OR ENFORCEABLE UNLESS BUYER'S WRITTEN NOTICE THEREOF IS RECEIVED BY SELLER WITHIN THREE (3) YEARS FROM THE DATE OF SELLER'S DELIVERY TO THE CARRIER AND (iii) SUCH WARRANTY WITH RESPECT TO THE MECHANICAL COMPONENTS, INCLUDING, WITHOUT LIMITATION, THE SIDEWINDER HOIST LEVER, OF ANY GOOD (OTHER THAN THE BRAKE DISCS ON ANY GOOD) SHALL BE VALID OR ENFORCEABLE UNLESS BUYER'S WRITTEN NOTICE THEREOF IS RECEIVED BY SELLER WITHIN ONE (1) YEAR FROM THE DATE ANY ALLEGED CLAIM ACCRUES. EXCEPT FOR THE WARRANTIES SET FORTH ABOVE, SELLER MAKES NO OTHER WARRANTIES WITH RESPECT TO THE GOODS OR ANY REPLACEMENT PARTS, WHETHER EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, QUALITY AND/OR THOSE ARISING BY STATUTE OR OTHERWISE BY LAW OR FROM ANY COURSE OF DEALING OR USE OF TRADE, ALL OF WHICH ARE HEREBY EXPRESSLY DISCLAIMED.

C. IN NO EVENT SHALL SELLER BE LIABLE TO BUYER OR ANY THIRD PARTY WITH RESPECT TO ANY GOOD OR REPLACEMENT PART, WHETHER IN CONTRACT, TORT OR OTHER THEORY OF LAW, FOR LOSS OF PROFITS OR LOSS OF USE, OR FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, DIRECT OR INDIRECT DAMAGES, HOWSOEVER CAUSED. SELLER'S MAXIMUM LIABILITY TO BUYER WITH RESPECT TO THE GOODS OR ANY REPLACEMENT PART SHALL IN NO EVENT EXCEED THE PRICE PAID BY BUYER FOR THE GOODS OR REPLACEMENT PART THAT ARE THE SUBJECT OF THE APPLICABLE CLAIM.

D. Seller shall not be liable for any damage, injury or loss arising out of the use of the Goods or any Replacement Part if, prior to such damage, injury or loss, such Goods or Replacement Parts are: (1) damaged or misused following Seller's delivery to the carrier; (2) not maintained, inspected, or used in compliance with applicable law and Seller's written instructions and recommendations; or (3) installed, repaired, altered or modified (a) with any part or accessory other than those supplied by Seller or (b) without compliance with such laws, instructions or recommendations.

E. This warranty is limited and provided only to the original end user. **Each Good and Replacement Part must be registered within sixty (60) days of receipt of each product to establish eligibility.** Please register at www.cmworks.com/hoist-warranty-registration or submit registration card via US mail.

F. Any action against Seller for breach of warranty, negligence or otherwise in connection with the electrical components of any Good must be commenced by Buyer within one (1) year after: (a) the date any alleged claim accrues; or (b) the date of delivery of the Goods to Buyer, whichever is earlier. Any action against Seller for breach of warranty, negligence or otherwise in connection with the brake discs on any Good must be commenced by Buyer within three (3) years after: (y) the date any alleged claim accrues; or (z) the date of delivery of the Goods to Buyer, whichever is earlier. Any action against Seller for breach of warranty, negligence or otherwise in connection with the mechanical components of any Good (other than the brake discs on any Good) must be commenced by Buyer within one (1) year after the date any alleged claim accrues. Any action against Seller for breach of warranty, negligence or otherwise in connection with any Replacement Part must be commenced by Buyer within one (1) year after: (y) the date any alleged claim accrues; or (z) the date of delivery of the Replacement Part to Buyer, whichever is earlier.

G. This warranty is contingent upon Buyer's proper maintenance and care of the Goods and/or Replacement Part, and does not extend to normal wear and tear. Seller reserves the right, at its option, to void this warranty in the event of Buyer's use with the Goods and/or Replacement Parts of parts or accessories other than those supplied by Seller.

WARNING

Alterations or modifications of equipment and use of non-Seller replacement parts can lead to dangerous operation and injury.

TO AVOID INJURY:

- Do not alter or modify equipment.
- Do use only replacement parts manufactured by seller.

HOOSIER CRANE SERVICE COMPANY



COLUMBUS McKINNON
CORPORATION

FAMILY OF BRANDS



USA: Ph: (800) 888.0985 • (716) 689.5400 • Fax: (716) 689.5644 • www.cmworks.com

CANADA: Ph: (877) 264.6478 • Fax: (877) 264.6477 • www.cmworks.com

UK: Ph: +44 1244 375375 • Fax: +44 1244 377403 • www.cmco.eu